



5-572.10
5H0762330001

January, 2020

INSTALLATION AND SERVICE MANUAL

indirect gas-fired weatherproof make-up air units

models HBP/HCP/HDP/HPP

OBP/OCPP/ODP/OPP



All models approved for use in California by the CEC.

⚠ WARNING

1. Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death, and could cause exposure to substances which have been determined by various state agencies to cause cancer, birth defects or other reproductive harm. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.
2. Installing, starting up and servicing heating, ventilation and air conditioning equipment poses significant hazards and requires specialized knowledge of Modine products and training in performing those services. Failure to have any service properly performed by, or making any modification to Modine equipment without the use of, qualified service personnel could result in serious injury to person and property, including death. Therefore, only qualified service personnel should work on any Modine products.

⚠ CAUTION

To prevent premature heat exchanger failure do not locate ANY gas-fired units in areas where chlorinated, halogenated, or acid vapors are present in the atmosphere.

FOR YOUR SAFETY

IF YOU SMELL GAS:

1. Open windows.
2. Don't touch electrical switches.
3. Extinguish any open flame.
4. Immediately call your gas supplier.

FOR YOUR SAFETY

The use and storage of gasoline or other flammable vapors and liquids in open containers in the vicinity of this appliance is hazardous.

IMPORTANT

The use of this manual is specifically intended for a qualified installation and service agency. A qualified installation and service agency must perform all installation and service of these appliances.

Inspection on Arrival

1. Inspect unit upon arrival. In case of damage, report it immediately to transportation company and your local factory sales representative.
2. Check rating plate on unit to verify that power supply meets available electric power at the point of installation.
3. Inspect unit upon arrival for conformance with description of product ordered (including specifications where applicable).

SPECIAL PRECAUTIONS

SPECIAL PRECAUTIONS

THE INSTALLATION AND MAINTENANCE INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED TO PROVIDE SAFE, EFFICIENT AND TROUBLE-FREE OPERATION. IN ADDITION, PARTICULAR CARE MUST BE EXERCISED REGARDING THE SPECIAL PRECAUTIONS LISTED BELOW. FAILURE TO PROPERLY ADDRESS THESE CRITICAL AREAS COULD RESULT IN PROPERTY DAMAGE OR LOSS, PERSONAL INJURY, OR DEATH. THESE INSTRUCTIONS ARE SUBJECT TO ANY MORE RESTRICTIVE LOCAL OR NATIONAL CODES.

HAZARD INTENSITY LEVELS

1. **DANGER:** Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.
2. **WARNING:** Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.
3. **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.
4. **IMPORTANT:** Indicates a situation which, if not avoided, MAY result in a potential safety concern.

DANGER

Appliances must not be installed where they may be exposed to a potentially explosive or flammable atmosphere.

WARNING

1. Failure to follow proper lifting instructions and applicable safety procedures could result in property damage, serious injury, or death. Lifting should only be done by a qualified rigging company. Use ALL lifting points. Test lift to ensure proper balance and rigging. Never lift in high winds.
2. All field gas piping must be pressure/leak tested prior to operation. Never use an open flame. Use a soap solution or equivalent for testing.
3. Gas pressure to appliance controls must never exceed 14" W.C. (1/2 psi).
4. Disconnect power supply before making wiring connections or working on this equipment. Follow all applicable safety procedures to prevent accidental power up. Failure to do so can result in injury or death from electrical shock or moving parts and may cause equipment damage.
5. All appliances must be wired strictly in accordance with wiring diagram furnished with the appliance. Any wiring different from the wiring diagram could result in a hazard to persons and property.
6. Any original factory wiring that requires replacement must be replaced with wiring material having a temperature rating of at least 105°C.
7. To reduce the opportunity for condensation, the minimum sea level input to the appliance, as indicated on the serial plate, must not be less than 5% below the rated input, or 5% below the minimum rated input of dual rated units.
8. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% greater than the rated voltage.

(continued next column)

WARNING

(continued from previous column)

9. When servicing or repairing this equipment, use only factory-approved service replacement parts. A complete replacement parts list may be obtained by contacting Modine Manufacturing Company. Refer to the rating plate on the appliance for complete appliance model number, serial number, and company address. Any substitution of parts or controls not approved by the factory will be at the owners risk.

CAUTION

1. Appliances are designed for outdoor installation only. DO NOT LOCATE APPLIANCES INDOORS.
2. Purging of air from gas lines should be performed as described in ANSI Z223.1 - latest edition "National Fuel Gas Code", or in Canada in CAN/CGA-B149 codes.
3. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% less than the rated voltage.
4. Do not reuse any mechanical or electrical component which has been wet. Such component must be replaced.

IMPORTANT

1. To prevent premature heat exchanger failure, do not locate ANY gas-fired appliances in areas where corrosive vapors (i.e. chlorinated, halogenated or acid) are present in the atmosphere.
2. To prevent premature heat exchanger failure, the input to the appliance, as indicated on the serial plate, must not exceed the rated input by more than 5%.
3. To prevent premature heat exchanger failure, observe heat exchanger tubes by looking at the heat exchanger through the field installed access openings in connecting ductwork or the unit access doors where viewing the heat exchanger is possible. If the bottom of the tubes become red while blower and duct furnace are in operation, check to be sure the blower has been set to the proper rpm for the application. Refer to page 19 for Blower Adjustments.
4. Start-up and adjustment procedures should be performed by a qualified service agency.
5. To check most of the Possible Remedies in the troubleshooting guide listed in Table 54.1, refer to the applicable sections of the manual.

SI (METRIC) CONVERSION FACTORS

To Convert	Multiply By	To Obtain	To Convert	Multiply By	To Obtain
"W.C.	0.24	kPa	CFH	1.699	m ³ /min
psig	6.893	kPa	Btu/ft ³	0.037	mJ/m ³
°F	(°F-32) x 0.555	°C	pound	0.453	kg
inches	25.4	mm	Btu/hr	0.000	kW
feet	0.305	meters	gallons	3.785	liters
CFM	0.028	m ³ /min	psig	27.7	"W.C.

TABLE OF CONTENTS

Table of Contents

Inspection on Arrival.....	1
Special Precautions.....	2
SI (Metric) Conversion Factors	2
Special Design Requests	4
Storage Prior to Installation	4
Unit Location	4
Combustible Material and Service Clearances	4
Sound and Vibration Levels	5
Curb or Sub-Base Mounting.....	5
Slab Mounting	6
Rigging Instructions.....	6
Duct Installation/Utility Connections.....	7
Venting.....	7
Unit Installation.....	8
Gas Connections	8
Considerations for Elevation.....	10
Electrical Connections	11
Evaporative Cooler	12
Cooling Coil Specifications and Installation.....	14
Start-Up Procedure	16
Pilot Burner Adjustment.....	16
Main Burner Adjustment	17
Blower Adjustment.....	19
Lubrication Recommendations	19
Damper Linkage Adjustment	19
Furnace Control Operating Sequence.....	20
Variable Air Volume Applications	21
Cooling Coil Operation	21
Component/Option Locations.....	22
Component Descriptions	22
General Performance Data	32
Pressure Drop Data.....	34
Blower Performance Data.	35
Blower Sheave Assembly Data	38
Dimensions.....	40
Weights.....	48
Maintenance.....	50
Service & Troubleshooting	54
Start-Up Checklist	57
Model Designations.....	58
Model Nomenclature	59
Commercial Warranty.....	Back Cover

SPECIAL DESIGN REQUESTS / UNIT LOCATION

SPECIAL DESIGN REQUESTS

Modine Manufacturing Company will sometimes build units with special features as requested by the customer. This manual only covers standard features and does not include any changes made for special feature requests by the customer. Units built with special features are noted with a 5-digit SPO (Special Product Order) Number on the Serial Plate

STORAGE PRIOR TO INSTALLATION

If the unit is stored outside prior to installation, the unit should be covered.

UNIT LOCATION

⚠ DANGER

Appliances must not be installed where they may be exposed to potentially explosive or flammable atmosphere.

⚠ CAUTION

Appliances are designed for outdoor installation only. DO NOT LOCATE APPLIANCES INDOORS.


IMPORTANT

To prevent premature heat exchanger failure, do not locate ANY gas-fired appliances in areas where corrosive vapors (i.e. chlorinated, halogenated or acid) are present in the atmosphere.

Location Recommendations

- When locating the furnace, consider general space and heating requirements and availability of gas and electrical supply.
- Unit must be installed on the positive pressure side of the circulating blower.
- Be sure the structural support at the unit location site is adequate to support the weight of the unit and any other required support structure. For proper operation the unit must be installed in a level horizontal position.
- Do not install units in locations where the flue products can be drawn into the adjacent building openings such as windows, fresh air intakes, etc.
- Be sure that the minimum clearances to combustible materials and recommended service clearances are maintained. Be sure clearances are maintained to the combustion air inlet louvers and power exhauster discharge cover. Units are designed for installation on non-combustible surfaces or combustible surfaces with the minimum clearances shown in Figure 4.1 and Table 4.2.
- On units that have fresh air openings, a method should be provided to prevent water and debris from entering the unit such as a rainhood and bird screen, evaporative cooler, etc.
- On horizontal discharge units (Model Digit 2=B or C), adequate space must be provided to install the discharge duct as shown in Figure 7.1. to insure even air flow across the heat exchanger.

Figure 4.1
Combustible Material & Service Clearances ①



① Minimum clearance to combustible materials is 1.0" from rooftop.

Table 4.2 - Combustible Material Clearances

Model Size	Minimum Combustible Material Clearances			Recommended Service Clearances	
	Access Side (A)	Front & Rear (B)	Non-Access Side (C)	Access Side (A)	Non-Access Side (C)
75	18"	3"	0"	36"	6"
100/125	20"	3"	0"	36"	
150/175	25"	3"	0"	42"	
200/225	27"	4"	0"	42"	
250/300	30"	5"	0"	48"	
350/400	41"	11"	0"	60"	
500/600	30"	5"	0"	48"	
700/800	41"	11"	0"	60"	
840/960	41"	11"	0"	60"	

SOUND ATTENUATION / ROOF CURB INSTALLATION


Sound and Vibration Levels

All mechanical equipment generates some sound and vibration that may require attenuation. For critical areas, an acoustical consultant should be retained to assist in the application. Locating the equipment away from the critical area is desirable within ducting limitations. Frequently, units can be located above utility areas, corridors, restrooms, and other non-critical areas. Generally, a unit should be located within 15 feet of a primary support beam to minimize structure deflections. Smaller deflections usually results in reduced vibration and noise transmission.

Install the unit over roof decking with 2" acoustic fiberglass lining within curb area for sound attenuation. The return air duct should be acoustically lined and should be installed with a flexible connection. If the ceiling space is used as a plenum, the acoustically lined return intake duct should form an inverted tee with five foot minimum legs in each direction.

The discharge duct should be acoustically insulated and should have a flexible connection as illustrated.

Figure 5.1 - Suggested Sound Attenuation




Curb or Sub-Base Mounted Sites

An optional roof curb is available to simplify site preparation and raise the unit above roof water and snow level for drainage. It can be installed with the roof, and in advance of the unit. A sub-base must be furnished by the installer if no curb is supplied for the roof. The sub-base, either steel or concrete, must provide required support with the unit bolted to sub-base. The following are some general guidelines for roof curb installed units:

1. The roof structure must be adequately designed to support the live weight load of the unit and any other required support structure. For the bearing loads normally encountered, the roof curb should be supported at points no greater than five feet apart. Additional truss reinforcement should be provided, if necessary.
2. Roof curb must be installed level. If roof is pitched it will be necessary to construct a sub-base on which to install the curb.
3. Roof curbs supplied by Modine are fabricated from 16 gauge galvanized steel and supplied knocked down for assembly on the job site. The curb consists of two side pieces, two end pieces, gasketing, four joiner angles, four 2x4 inch wood nailing strips, nuts, bolts, and washers. Roof curbs over 120 inches long include two additional side pieces and two splice plates. Refer to the latest revision of Modine literature 5-590 for instructions.
4. Outside dimensions must be held when installing curb. Top surface must be level and straight to insure weather-tightness. All corners must be square.
5. Final electric and gas connections must be made after unit is installed to allow for tolerance in setting of unit on curb. For electrical power supply allow approximately eight feet of wire, plus provisions for weathertight flexible conduit for connection to unit, as required by local codes.
6. Maintain an 12-inch minimum height from top of roof deck to top of curb.
7. Caulk butt joints after curb is assembled and installed on roof structural members and roof flashing is added.

Figure 5.2 - Typical Curb Details



SLAB MOUNT INSTALLATION / RIGGING INSTRUCTIONS

Slab Mounted Units

For Horizontal Discharge (Model Digit 2=B or C)

For ground level installation of a horizontal-discharge unit, prepare a level concrete slab at least four inches thick on adequate footings and a generous bed of gravel for drainage (See Figure 6.1). The slab should include threaded 5/8-inch anchor bolts spaced as shown in Figure 6.1 and Table 6.1. Anchor bolts should extend at least 1-1/2" above the surface of the pad to allow clearance for mounting washers, nuts and bolts (mounting washers, nuts and bolts by others). The slab should extend out at least six inches around the perimeter of the unit.

Figure 6.1 - Slab-Mounted Make-Up Air Unit




Table 6.1 - Slab Anchor Bolt Dimensions

Digit 2	Model Size	Blower Type (Digit 16)	A	B
B	75	All	82.91	33.85
	100/125	All	82.91	36.36
	150/175	All	82.91	40.61
	200/225	All	82.91	42.71
	250/300	E, F, G, or H	82.91	45.75
		I, J, or K	118.50	45.75
	350/400	E, F, G, or H	82.91	57.27
		I, J, or K	118.50	57.27
	500/600	G or H	116.03	45.75
		I, J, K, or L	151.62	45.75
C	700/800	G or H	116.03	57.27
		I, J, K, or L	151.62	57.27
	840/960	All	185.02	57.27
	75	All	106.89	33.85
	100/125	All	106.89	36.36
	150/175	All	106.89	40.61
	200/225	All	106.89	42.71
	250/300	E, F, G, or H	106.89	45.75
		I, J, or K	142.48	45.75
	350/400	E, F, G, or H	106.89	57.27
		I, J, or K	142.48	57.27

General Rigging Instructions

⚠ WARNING


Failure to follow proper lifting instructions and applicable safety procedures could result in property damage, serious injury, or death. Lifting should only be done by a qualified rigging company. Use ALL lifting points. Test lift to ensure proper balance and rigging. Never lift in high winds.

Rigging and lifting of the units should only be done by a qualified rigging company and follow appropriate industry standards, including but not limited to the appropriate sections of ASME B30, OSHA 1910, and OSHA 1926.

Four 3/4-inch holes at the extended ends of the mounting channels are supplied to facilitate lifting the unit with eyebolts furnished by the installer. With the lifting points identified, the units can be lifted by crane or helicopter.

- Follow site preparation instructions for the roof curb, slab, or equipment stand before installation.
- Check the Serial Plate(s) of unit with plans to be sure unit is properly located. Although units may look outwardly similar, their function, capacities, options, and accessories will often vary.
- Check unit dimensions of both the unit base and the curb or stand on which the unit will be installed.
- If the unit will be installed on a roof curb:
 - Thoroughly clean and dry the top of the curb surface.
 - Lay a bead of weather resistant caulking on top perimeter of roof curb as illustrated in Figure 5.2. Note: If roof curb is supplied by Modine, full perimeter gasket material is supplied and caulking is not necessary.
- When lifting the equipment, connect sturdy steel cables, chains, or straps with eye loops as illustrated in Figure 6.2. For stability in lifting and lowering and to prevent damage to the unit, include a spreader bar as shown in Figure 6.2. Avoid twisting or uneven lifting of the unit. The cable length from the lifting point on the unit to the spreader bar should always be longer than the distance between the outer lifting points.
- Test lift the unit to check for proper rigging balance before hoisting to the desired installation location.
- Once lifted to the installation location, orient the hoisted unit to match the ductwork locations and set evenly on the curb or stand.
- Following the instructions in this manual, make final unit connections for ductwork, utilities, and controls.

Figure 6.2 - Typical Rigging




DUCT INSTALLATION / UTILITY CONNECTIONS

Duct Installation


1. The blower section inlet and/or return air connections, as well as the furnace furnace discharge are designed to accept 90° flanged ductwork as shown in Figure 7.1. To determine locations and dimensions of connections, refer to the dimensional drawings later in this manual.

Figure 7.1 - Duct Connections




2. Provide an airtight seal between the ductwork and the unit. Seams with cracks in the ductwork should be permanently caulked and/or taped. All duct connections outside the building **MUST** be weathertight to prevent rain and snow from entering the ductwork.
3. Acoustic duct liners are recommended on all internal supply and return air ducts.
4. Provide uniform air distribution over the heat exchanger. Use turning vanes in the supply ductwork where required to obtain uniform air distribution. See Figure 7.2.

Figure 7.2 - Recommended Discharge Duct Configs



5. On horizontal discharge units with Model Digit 2=B, provide removable access panels on the downstream side of the unit as shown in Figure 7.1. These openings should be large enough to view smoke or reflect light inside the casing to indicate leaks in the heat exchanger and to check for hot spots on the heat exchanger due to a lack of sufficient airflow (CFM). This is not required on horizontal discharge units with Model Digit 2=C because the cooling coil cabinet access door can be removed for this purpose.
6. When a roof curb is used in conjunction with a factory supplied return air connector, the ductwork can be fastened to the connectors prior to the unit installation. The connectors will accept 90° flanged ductwork. See Figure 7.3.

Figure 7.3 - Discharge and/or Return Air Connectors



Utility Connections

Utility and control connections can be made to the unit from the bottom for roof curb-mounted units or through the fixed side panels for horizontal supply and return units. Holes can be made in fixed side panels to accommodate utility connections as specified according to the unit dimensional drawings. Sealing of holes cut in the unit casing for utility connections should be done with care to prevent air and water leaks.

Venting

1. Installation of venting must conform with local building codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) - Latest Edition. In Canada, installation must be in accordance with CAN/CGA-B149.1 for natural gas units and CAN/CGA-B149.2 for propane units.
2. Units are shipped with the power exhauster discharge cover factory installed.
3. Do not modify or obstruct the combustion air inlet louvers or the power exhauster discharge cover.
4. Do not add any vents other than those supplied by the manufacturer.

UNIT INSTALLATION

Gas Connections

! WARNING

1. All field gas piping must be pressure/leak tested prior to operation. Never use an open flame. Use a soap solution or equivalent for testing.
2. Gas pressure to appliance controls must never exceed 14" W.C. (1/2 psi).
3. To reduce the opportunity for condensation, the minimum sea level input to the appliance, as indicated on the serial plate, must not be less than 5% below the rated input, or 5% below the minimum rated input of dual rated units.

! CAUTION

Purging of air from gas supply line should be performed as described in ANSI Z223.1 - latest edition "National Fuel Gas Code", or in Canada in CAN/CGA-B149 codes.

IMPORTANT

To prevent premature heat exchanger failure, the input to the appliance, as indicated on the serial plate, must not exceed the rated input by more than 5%.

1. Installation of piping must conform with local building codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) - Latest Edition. In Canada, installation must be in accordance with CAN/CGA-B149.1 for natural gas units and CAN/CGA-B149.2 for propane units.
2. Piping to units should conform with local and national requirements for type and volume of gas handled, and pressure drop allowed in the line.
3. Refer to Model Digits 4-6 of the Model Nomenclature on page 59 and the value on the unit Model ID plate (not individual furnace serial plates) to determine the gas heating capacity in Thousands of Btu/hr (MBH). The Model ID plate is located on the blower section electrical compartment door. See Figure 8.1 for an example Model ID plate.


Figure 8.1 - Model ID Plate Example

MODEL IDENTIFICATION PLATE				MODEL NUMBER		Modine Manufacturing Company Phone: 1-800-828-4328	
VOLTAGE	HERTZ	PHASE		HP	15.0	1500 Dekoven Avenue, Racine, WI 53403-2552	
460	60	3		HP	15.0	Design conforms to: UL 1995, ANSI Z83.8 - 2016 & CSA C22.6 - 2016	
AMPS	HP			ORDER	38100917990819-3193	Complies to: CAN/CGA B149.1 & B149.2	
21.00				ORDER	38100917990819-3193	FOR SERVICE, contact your local qualified installation and service contractor or	
SUPPLY VOLTAGE	HERTZ	PHASE		ORDER	V415712	appropriate utility company. FOR PARTS ORDERING, contact the parts	
460	60	3		ORDER	18695	wholesaler or the manufacturer's representative serving your area. When	
FLA	MCA	MOP (TIME DELAY)		ORDER	18695	inquiring about parts, always provide model number, serial number, description	
24	28	45		ORDER	18695	and part number. When ordering parts, provide part number listed.	
Short circuit current 5kA rms				Made in U.S.A.			

4. For the length of pipe necessary, determine the pipe diameter from Tables 9.1 or 9.2 for the unit heating capacity. Where several units are served by the same main, the total capacity and length of main must be considered. While the gas connection(s) on the unit may be smaller than the required supply pipe diameter, do not use pipe sizes smaller than what is required leading up to the unit. At the unit, reduce the pipe size down to the appropriate size (sizes 75-225 are 1/2" connections, 250-960 are 3/4" connections). Avoid pipe sizes smaller than 1/2". The inlet pressure to the unit must be 6-7" W.C. for natural gas and 11-14" W.C. for propane gas. When sizing the inlet gas pipe diameter, be sure the unit supply pressure can be met after the line pressure drop has been subtracted. If the line pressure drop is too high, refer to NFPA 54 National Fuel Gas Code for other gas pipe capacities.

5. The gas piping to the unit can enter the unit from the side of the unit or from below. Install a ground joint union with brass seat and a manual shut-off valve external of the unit casing, and adjacent to the unit for emergency shut-off and easy servicing of controls, including a 1/8" NPT plugged tapping accessible for test gauge connection (See Figure 8.2). Verify the manual shut-off valve is gas tight on an annual basis.
6. Provide a sediment trap before each unit in the line where low spots cannot be avoided. (See Figure 8.2).

Figure 8.2
Recommended Sediment Trap/Manual Shut-off Valve Installation - Side or Bottom Gas Connection



7. When Pressure/Leak testing, pressures above 14" W.C. (1/2 psi), close the field installed shut-off valve, disconnect the appliance and its combination gas control from the gas supply line, and plug the supply line before testing. When testing pressures 14" W.C. (1/2 psi) or below, close the manual shut-off valve on the appliance before testing.

INSTALLATION

Table 9.1 - Gas Pipe Capacities - Natural Gas ①

Pipe Length (ft)	Capacity in MBH by Nominal Pipe Diameter							
	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
10	138	287	540	1,113	1,659	3,203	5,103	9,009
20	95	197	371	762	1,145	2,195	3,507	6,195
30	76	159	298	612	917	1,764	2,814	4,977
40	65	135	255	524	784	1,512	2,405	4,253
50	58	120	226	464	695	1,344	2,132	3,770
60	53	109	205	420	630	1,218	1,932	3,423
70	48	100	188	386	580	1,113	1,775	3,150
80	44	93	175	360	540	1,038	1,659	2,930
90	42	87	165	338	506	974	1,554	2,741
100	40	83	155	319	478	921	1,470	2,594
125	35	74	138	282	423	816	1,302	2,300
150	32	66	125	256	384	739	1,176	2,079
175	29	61	114	235	353	680	1,082	1,911
200	27	57	107	219	329	632	1,008	1,785
250	24	50	95	194	291	561	894	1,575

① Gas pipe capacities based on Table 6.2.1(a) of NFPA 54 for schedule 40 metallic pipe with inlet pressure less than 2 psi, with a pressure drop of 0.3" w.c. and gas specific gravity of 0.60.

Table 9.2 - Gas Pipe Capacities - Propane Gas ②

Pipe Length (ft)	Capacity in MBH by Nominal Pipe Diameter							
	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
10	291	608	1,150	2,350	3,520	6,790	10,800	19,100
20	200	418	787	1,620	2,420	4,660	7,430	13,100
30	160	336	632	1,300	1,940	3,750	5,970	10,600
40	137	287	541	1,110	1,660	3,210	5,110	9,030
50	122	255	480	985	1,480	2,840	4,530	8,000
60	110	231	434	892	1,340	2,570	4,100	7,250
80	101	212	400	821	1,230	2,370	3,770	6,670
100	94	197	372	763	1,140	2,200	3,510	6,210
125	89	185	349	716	1,070	2,070	3,290	5,820
150	84	175	330	677	1,010	1,950	3,110	5,500
175	74	155	292	600	899	1,730	2,760	4,880
200	67	140	265	543	814	1,570	2,500	4,420
250	62	129	243	500	749	1,440	2,300	4,060

② Gas pipe capacities based on Table 6.3.1(d) of NFPA 54 for schedule 40 metallic pipe with inlet pressure of 11.0" w.c., with a pressure drop of 0.5" w.c. and gas specific gravity of 1.50.

Table 9.3 - Burner Orifice Sizing and Gas Consumption

Model Size		Gas Type		Orifice Qty
		Natural ①	Propane ②	
75	Cfh	72.1	30.0	1
	Orifice Drill Size	20	39	
100	Cfh	96.1	40.0	2
	Orifice Drill Size	30	45	
125	Cfh	120.2	50.0	2
	Orifice Drill Size	25	42	
150	Cfh	144.2	60.0	3
	Orifice Drill Size	30	45	
175	Cfh	168.3	70.0	3
	Orifice Drill Size	27	43	
200	Cfh	192.3	80.0	3
	Orifice Drill Size	23	42	
225	Cfh	216.3	90.0	3
	Orifice Drill Size	20	39	
250	Cfh	240.4	100.0	4
	Orifice Drill Size	25	42	
300	Cfh	288.7	120.0	4
	Orifice Drill Size	20	39	
350	Cfh	336.5	140.0	6
	Orifice Drill Size	27	43	
400	Cfh	384.6	160.0	6
	Orifice Drill Size	23	42	
500 ③	Cfh	240.4	100.0	4
	Orifice Drill Size	25	42	
600 ③	Cfh	288.7	120.0	4
	Orifice Drill Size	20	39	
700 ③	Cfh	336.5	140.0	6
	Orifice Drill Size	27	43	
800 ③	Cfh	384.6	160.0	6
	Orifice Drill Size	23	42	
840 ④	Cfh	336.5	140.0	6
	Orifice Drill Size	27	43	
960 ④	Cfh	384.6	160.0	6
	Orifice Drill Size	23	42	

① Based on natural gas properties of 1050 Btu/ft³ and specific gravity of 0.60.
 ② Based on propane gas properties of 2500 Btu/ft³ and specific gravity of 1.50.
 ③ Model sizes 500-800 contain 2 furnaces. Values shown are per furnace.
 ④ Model sizes 840-960 contain 3 furnaces. Values shown are per furnace.

INSTALLATION

Considerations for Elevation

The standard ratings for the duct furnace(s) used in these units are certified for elevations up to 2000 feet above sea level. Operation at elevations above 2,000 feet requires ratings be reduced 4% for each 1000 feet above sea level per ANSI Z223.1. The exception is for units in Canada, CSA requires that ratings be reduced 10% for elevations between 2,001 and 4500 feet. The following instructions are for units that will be installed over 2,000 feet elevation. If this does not apply, you may skip ahead to the Electrical Connections section on page 11.

Manifold Pressure Adjustment

The unit manifold pressure is factory set for operation at elevations up to 2000 feet as follows:

- For **Natural Gas** units, 3.5" W.C. based on a gas heating value of 1,050 BTU/ft³.
- For **Propane Gas** units, 10.0" W.C. based on a gas heating value of 2,500 BTU/ft³.

For higher elevations, some utility companies may derate the BTU content (heating value) of the gas provided at altitude to a lower value to allow certain heating appliances to be used with no manifold pressure adjustments. For this reason it is necessary that the supplying utility be contacted for detailed information about the gas type and BTU content (heating value) before operating any heater. Table 10.1 shows the standard derated heating values of natural and propane gases at various elevations.

Table 10.1
Gas Heating Values at Altitude (Btu/ft³) ①②③⑤

Altitude (ft)	Natural Gas	Propane
0-2,000	1,050	2,500
2,001-3,000	929 ③	2,212 ④
3,001-4,000	892 ③	2,123 ④
4,001-4,500	874 ③	2,080 ④
4,501-5,000	856	2,038
5,001-6,000	822	1,957
6,001-7,000	789	1,879
7,001-8,000	757	1,803
8,001-9,000	727	1,731
9,001-10,000	698	1,662

- ① Values shown are for 3.5" W.C. manifold pressure for Natural Gas and 10.0" W.C. for Propane Gas. If the local utility supplies gas with a different Btu/ft³ value, use Equation 10.1 to calculate the required manifold pressure.
- ② Gas heating values shown are derated 4% per 1,000' of elevation (10% between 2,000' and 4,500' elevation in Canada) in accordance with ANSI Z223.1 and CSA-B149, respectively.
- ③ 945 Btu/ft³ for Canada
- ④ 2,250 Btu/ft³ for Canada
- ⑤ When installed at altitudes above 2,000', a pressure switch may need to be changed. Refer to Tables 10.2 and 10.3 to determine if a switch change is required.

If the utility is supplying gas with heating values **SAME** as shown in Table 10.1, the manifold pressure should remain set to 3.5" W.C. for natural gas and 10.0" W.C. for propane gas and you may proceed to the section on this page titled "Selection of the Proper High Altitude Kit".

If the utility is supplying gas with heating values **DIFFERENT** than shown in Table 10.1, use Equation 10.1 to determine the appropriate manifold pressure for the elevation and gas heating value being supplied. Note what that value is, as it will be needed later for Start-Up. Proceed to the section on this page titled "Selection of the Proper High Altitude Kit".

Equation 10.1 - Manifold Pressure for Gas Heating Values Different Than Shown in Table 10.1

$$MP_{ELEV} = \left(\frac{BTU_{TBL}}{BTU_{ACT}} \right)^2 \times MP_{SL}$$

Where:

MP_{ELEV} = Manifold Pressure (" W.C.) at installed elevation

BTU_{TBL} = BTU/ft³ content of gas from Table 10.1

BTU_{ACT} = BTU/ft³ content of gas obtained from the utility company

MP_{SL} = Manifold Pressure (" W.C.), at Sea Level (use 3.5" W.C. for natural gas and 10.0" W.C. for propane)

NOTE: For units equipped with two-stage or modulating gas controls, only the high fire manifold pressure needs to be adjusted. No adjustments to the low fire manifold pressure are necessary on these units.

Selection of the Proper High Altitude Kit

All units installed at elevations greater than 2000 feet above sea level require a kit, in addition to potential manifold pressure adjustment outlined in the previous step. To determine the proper kit to use, refer to Table 10.2.

Table 10.3 shows the contents of the kit. For more information, refer to the latest revision of Modine Bulletin 75-530.

Table 10.2 - High Altitude Kit Selection Table ①②③

Model	Model Size		Elevation Above Sea Level (ft)		
			2,001-5,500	5,501-6,500	6,501-7,500
All	All	Item Code	67248	67248	67248

- ① Applies to both installations in the U.S. and Canada.
- ② Applies to both natural and propane gas.
- ③ Sizes 75-400 require a kit qty. of 1, sizes 500-800 require a kit qty of 2, sizes 840-960 require a kit qty of 3.

Table 10.3 - High Altitude Kit Contents

Item Code	Kit Contents		
	High Altitude Conversion Label	Pressure Switch	Installation Instructions
67248	Yes	No	Yes

If a unit is to be installed at higher elevations AND converted from natural gas to propane gas operation, a propane conversion kit must be used in conjunction with the manifold pressure adjustment and high altitude kit listed above. For the Selection and Installation Instructions for propane conversion kits, please see the latest revision of Modine Bulletin 75-511.

UNIT INSTALLATION

Electrical Connections

WARNING

1. Disconnect power supply before making wiring connections or working on this equipment. Follow all applicable safety procedures to prevent accidental power up. Failure to do so can result in injury or death from electrical shock or moving parts and may cause equipment damage.
2. All appliances must be wired strictly in accordance with wiring diagram furnished with the appliance. Any wiring different from the wiring diagram could result in a hazard to persons and property.
3. Any original factory wiring that requires replacement must be replaced with wiring material having a temperature rating of at least 105°C.
4. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% greater than rated voltage.

CAUTION

1. Ensure that the supply voltage to the appliance, as indicated on the serial plate, is not 5% less than the rated voltage.
2. Do not reuse any mechanical or electrical component which has been wet. Such components must be replaced.
1. Installation of wiring must conform with local building codes, or in the absence of local codes, with the National Electric Code ANSI/NFPA 70 - Latest Edition. Unit must be electrically grounded in conformance to this code. In Canada, wiring must comply with CSA C22.1, Part 1, Electrical Code.
2. Two copies of the job specific wiring diagram are provided with each unit, one located in the duct furnace electrical junction box and one in the electrical section of the unit located in the blower compartment. Refer to this diagram for all wiring connections.
3. External electrical connections to be installed include:
 - Supply power (120, 208, 240, 480, or 600 volts).
 - Thermostats, remote monitoring panels, building pressure sensors, time clocks, or any other accessory control devices that may be supplied (24 volts).
4. All supply power electrical connections are made in the electrical section of the unit. The low voltage (thermostat and accessory control devices) may be wired to either the electrical section or the duct furnace electrical junction box. Refer to the wiring diagram for the terminal location of all low voltage wiring.
5. Refer to the unit dimensional drawings in this document for the location of the drill locator dimples in the side and bottom of the unit for field drilling the hole for the electrical conduit entry.
6. Control wiring consists of both 24V analog control wiring and for models with Model Digit 12=9, low current digital control signal wiring. To avoid signal interference, the two types should be run in conduit separate from power wiring. The analog control wiring should be shielded at one end of the wiring run. Wiring should be stranded, twisted, and shielded communication wire.


7. The wire gauge must be sized according to the National Electric Code or CSA code based on amp draw and length of run. Refer to Table 11.1 for maximum wire lengths that can be wired between components and the terminal block on the unit based on the wire gauge being used.

Table 11.1 - 24V and Digital Control Wire Lengths

Minimum Recommended Wire Gauge	Maximum Distance (feet) from Control Device to Unit	
	24V Control Wiring	Digital Control Wiring
22	n/a	120
20	n/a	200
18	75	300
16	125	500
14	175	n/a

8. **FOR UNITS WITH MODEL DIGIT 12=9 (MODINE CONTROL SYSTEM OPTION):** For field wiring to the factory terminal strip, the terminal strip connections are designed to clamp down on the wires. To properly connect the wires to the terminal strip:
 - Push a small flat-head screwdriver into the square hole on the terminal. Press firmly until the screwdriver hits the back stop and opens the terminal (see Figure 11.1).
 - Remove approximately 3/8" of insulation from the end of the wire and push the stripped wire into the oval hole in the terminal.
 - Remove the screwdriver. Pull on the wire to make sure that it is securely clamped in the terminal.
 - Make sure that the terminal clamp is in contact with bare wire (insulation removed).

Figure 11.1 - Terminal Strip Wiring (Model Digit 12=9)




(continued next page)

ELECTRICAL CONNECTIONS

9. Depending on the configuration of the unit controls, there may be sensors that are field installed. Review the unit ordered to verify that the sensors supplied match the configuration of the unit. The following are sensors that may be included for field installation (for installation instructions, refer to the instructions included with the individual sensors):
 - **Supply Air Temperature Sensor**
This sensor is required on all units and is mounted in the supply air ductwork downstream of the unit discharge.
 - **Outdoor Air Sensor**
This sensor is required on all units except 100% return air units. Depending on the unit configuration, the sensor may be duct mounted or remote mounted.
 - **Return Air Sensor**
This sensor is required on all units that have a mixture of outside and return air. The sensor is mounted in the return air ductwork.
 - **Space Temperature/Humidity Sensor**
This sensor is required on all units that have space temperature/humidity reset control.
 - **Building Pressure Sensor**
This sensor is required on all units that have space pressure control, either through modulating dampers or variable frequency drive control on the supply air blower.
 - **Duct Pressure Sensor**
This sensor is required on all units that have duct pressure control through variable frequency drive control on the supply air blower.
 - **Space CO₂ Sensor**
This sensor is required on all units that have demand based ventilation control based on space CO₂ concentration.
 - **Duct Mounted Smoke Detector**
This sensor is mounted in the supply air or return air ductwork.

For further instructions on the above sensor(s), refer to the installation instructions that shipped with the sensor(s).
10. Make sure all multi-voltage components (motors, transformers, etc.) are wired in accordance with the power supply voltage.
11. The power supply to the unit must be protected with a fused or circuit breaker disconnect switch. Refer to the Factory Mounted Option Locations (Figure 22.1) for the factory mounted disconnect switch location and then review the unit to determine if a factory installed dead front disconnect switch was provided. Accessory field installed disconnect switches should be mounted where required by the National Electric Code as shown in Figure 12.1. For fusible disconnect switches, refer to the Model Identification plate for the fuse size and type.
12. The power supply must be within 5% percent of the voltage rating and each phase must be balanced within 2 percent of each other. If not, advise the utility company.
13. All outdoor electrical connections must be weatherized to prevent moisture from entering the electrical compartment.

Figure 12.1 - Recommended Accessory Field Installed Disconnect Switch Mounting Locations



Evaporative Cooler Installation

For units equipped with an evaporative cooler (Model Digit 22=D), refer to Installation and Service Manual - Evaporative Coolers (Literature 5-588).

Figure 12.2 - Evaporative Cooler (Model Digit 22=D)



THIS PAGE INTENTIONALLY LEFT BLANK

UNIT INSTALLATION


Cooling Coil Units

Units with a cooling section (Model Digit 2=C or P) can be provided with a factory installed direct expansion (DX) coil, a chilled water (water or water/glycol mixtures) coil, or the coil can be field supplied and installed by others. For units equipped with a factory installed cooling coil (Model Digit 23=1), refer to the packing slip to determine the coil type provided.

The section includes a full coverage, 3-way sloping stainless steel drain pan to remove condensate from coil headers and piping components. Insulation is standard on outdoor units and optional on indoor units. The cabinet includes two doors, a removable upper door for service access to the coil once the plumbing has been installed and a lower door which includes a 1" drain connection to the exterior of the cabinet. Field connections for coil inlet and outlet piping can be made through the cabinet corner post or back of the unit. The cooling section duct transition includes 1-1/2" flanges for fastening the sides of the coil. The bottom duct transition is angled to remove any condensation that may be entrained in the supply air stream.

For field supplied coils, do not exceed the maximum coil dimensions listed in Literature 82-135. If the coil supplied is smaller than the listed dimensions, field supplied blank off plates are required to prevent air bypass around the coil. The coil is supported by two 14 gauge support rails which contain mounting provisions for fastening 4", 5", 6", 7.5", 8.5", and 10" deep coils.

Figure 14.1 - Cooling Section (DX Coil Shown)




Condensate Drain Pan Trap

The condensate drain line needs to include a P-trap immediately downstream of the connection to the unit. This trap should extend at least two inches below the connection to prevent air pressure from forcing air into the unit. The trap should be primed with a water/glycol solution to prevent freezing.

Direct Expansion (DX) Piping

The refrigerant lines should be insulated to prevent warming or cooling of the refrigerant. If the suction line is allowed to be cooled, liquid will condense in the line and can severely damage the compressor. If the liquid line is warmed, the refrigerant can "flash" into a gas. This will cause erratic operation of the expansion device and impair the heat transfer ability of the cooling coil. Long runs of piping need to be periodically supported to prevent excess vibration that can damage the piping and joints. It is recommended to provide dampening supports at intervals of length equivalent to 15 tube diameters.

Figure 14.2 - General DX Piping



1. Inspect the refrigerant distributor and verify that the nozzle is in place.
2. All field brazing welding should be performed using high quality materials and an inert gas purge (such as nitrogen) to reduce oxidation of the internal surface of the coil.
3. The use of filter-driers in the system piping is recommended along with a sight glass that has a moisture indicator.
4. Connect the suction line and suction connection.
5. Install the expansion valve (by others). Follow the expansion valve manufacturer's recommendations for installation to avoid damaging the valve.
6. Connect the liquid line to the expansion valve. Pressurize the coil, expansion valve assembly and suction connection to 100 psig with dry nitrogen or other suitable gas. The coil should be left pressurized for a minimum of 10 minutes.
7. If the coil holds pressure, the installation can be considered leak free. If the pressure drops by 5 psi or less, repressurize the coil and wait another 10 minutes. If the pressure drops again, there are more than likely one or more small leaks, which should be located and repaired. Pressure losses greater than 5 psi would indicate a larger leak, which should be isolated and repaired. Be sure to check valves and fittings as potential sites for leakage or bleed.
8. Use a vacuum pump to evacuate the coil and any interconnecting piping that has been open to atmosphere. Measure the vacuum in the piping using a micron gauge located as far from the pump as possible (the vacuum at the pump will be greater than the rest of the system). Evacuate the coil to 500 microns or less then close the valve between the pump and the system. If the vacuum holds to 500 microns or less for one minute, the system

UNIT INSTALLATION

is ready to be charged or refrigerant pumped down in another portion of the system can be opened to the coil. A steady rise in microns would indicate that moisture is still present and that the coil should be further vacuumed until the moisture has been removed.

9. Failure to obtain a high vacuum is indicative of a great deal of moisture or a small leak. Break the vacuum with a charge of dry nitrogen or other suitable gas and recheck for leaks (soapy water works well). If no leaks are found, continue vacuuming the coil until the desired vacuum is reached.
10. All field piping must be self-supporting.

Chilled Fluid Piping

To prevent noise and coil damage from water hammer, an air vent is necessary to bleed off the accumulated air in the system. The vent should be located on the top of the inlet manifold where the air collects. This vent should be opened twice a year.

The outlet manifold should have a drain installed on the bottom to allow for periodic flushing of the system to remove sediments and corrosion products from the cooling coil. This drain should be opened to allow some fluid to drain twice a year. Check coloration and viscosity of the effluent for indications of corrosion in the system. The lines between the unit and the structure should be insulated to prevent freezing of the water.

1. Once installed, the coil should be pressurized to 100 psig with dry nitrogen or other suitable gas. The coil should be left pressurized for a minimum of 10 minutes. If the coil holds the pressure, the hook-up can be considered leak free. If the pressure drops by 5 psig or less re-pressurize the coil and wait another 10 minutes. If the pressure drops again, there is more than likely one or more small leaks which should be located and repaired. Pressure losses greater than 5 psig would indicate a larger leak that should be isolated and repaired.
2. All field brazing and welding should be performed using high quality materials and an inert gas purge (such as nitrogen) to reduce oxidation of the internal surface of the coil.
3. All field piping must be self supporting. System piping should be flexible enough to allow for thermal expansion and contraction of the coil.
4. Fill the coil with water with all air vents open so that air is eliminated from within the coil circuitry and headers. Verify that all vents and drains are not obstructed and do discharge a stream of water.
5. Close all vents and perform a hydrostatic leak test of all brazed, threaded or flanged joints, valves and interconnecting piping. Recheck the coil level and correct if necessary. When the setup is found to be leak free, discharge and discard initial water charge. It is important that all grease, oil, flux and sealing compounds present from the installation be removed.

Figure 15.1 - General Chilled Fluid Piping




Table 15.1 - Cooling Coil Performance Limits

Cooling Type	Model Size	Min CFM	Single Circuit		Dual Circuit		Max Cooling (Tons) ②
			Max CFM ①	Area (ft²)	Max CFM ①	Area (ft²)	
DX	75	688 ③	1,891	3.44	1,707	3.10	9.4
	100	802 ④	2,206	4.01	2,048	3.72	11.4
	125	926					
	150	1,111	2,521	4.58	2,416	4.39	13.4
	175	1,296					
	200	1,481	3,352	6.09	3,165	5.76	18.1
	225	1,667					
	250	1,852	3,724	6.77	3,538	6.43	20.2
	300	2,222					
	350	2,593	5,214	9.48	4,996	9.08	27.3
	400	2,963					
Chilled Water	75	609	1,676	3.05	n/a	n/a	10.6
	100	741	2,011	3.66	n/a	n/a	12.6
	125	926					
	150	1,111	2,372	4.31	n/a	n/a	14.8
	175	1,296					
	200	1,481	3,214	5.84	n/a	n/a	19.3
	225	1,667					
	250	1,852	3,592	6.53	n/a	n/a	21.3
	300	2,222					
	350	2,593	5,073	9.22	n/a	n/a	29.3
	400	2,963					

① Based on 550 feet per minute (FPM) coil face velocity.

② Based on 95°F/75°F Entering Dry Bulb/Wet Bulb.

③ Model Size 75 minimum CFM for DX Dual Circuit is 621.

④ Model Size 100 minimum CFM for DX Dual Circuit is 745.

START-UP PROCEDURE

Start-Up Procedure

IMPORTANT

1. To prevent premature heat exchanger failure, observe heat exchanger tubes by looking at the heat exchanger through the field installed access openings in connecting ductwork or the unit access doors where viewing the heat exchanger is possible. If the bottom of the tubes become red while blower and duct furnace are in operation, check to be sure the blower has been set to the proper rpm for the application. Refer to page 16 for Blower Adjustments.
2. Start-up and adjustment procedures should be performed by a qualified service agency.

Refer to page 58 for the Start-up Checklist.

1. Turn off power to the unit at the disconnect switch. Check that fuses or circuit breakers are in place and sized correctly. Turn all hand gas valves to the "OFF" position.
2. Remove the blower exterior panels and open the electrical compartment door.
3. Check that the supply voltage matches the unit supply voltage listed on the Model Identification plate. Verify that all wiring is secure and properly protected. Trace circuits to insure that the unit has been wired according to the wiring diagram.
4. Check to insure that the venting system is installed and free from obstructions.
5. Check to see that there are no obstructions to the intake and discharge of the unit.
6. Check the belt tension and sheave alignment. Refer to Blower Adjustments for proper belt tension.
7. Check bearings for proper lubrication. For units provided with pillow block bearings (See Model Nomenclature), refer to Lubrication Recommendations for requirements.
8. Check to make sure that all filters are in place and that they are installed properly according to direction of air flow.
9. Perform a visual inspection of the unit to make sure no damage has occurred during installation.
10. Turn on power to the unit at the disconnect switch. Check to insure that the voltage between duct furnace electrical box terminals 1 and 2 is 24V.
11. Check the thermostat, ignition control, gas valve, and supply fan blower motor for electrical operation. If these do not function, recheck the wiring diagram. Check to insure that none of the Control Options have tripped.
12. For units with a return air damper, the return air damper linkage needs to be adjusted. Refer to Damper Linkage Adjustment.
13. Check to make sure that the damper opens properly without binding.
14. Check the blower wheel for proper direction of rotation when compared to the air flow direction arrow on the blower housing. Blower wheel rotation, not air movement, must be checked as some air will be delivered through the duct furnace with the blower wheel running backwards.
15. Check the blower speed (rpm). Refer to Blower Adjustments for modification.
16. Check the motor speed (rpm).
17. Check the motor voltage. On three phase systems, check to make sure all legs are in balance.
18. Check the motor amp draw to make sure it does not exceed the motor nameplate rating. On three phase systems, check all legs to insure system is balanced.
19. Recheck the gas supply pressure at the field installed manual shut-off valve. The minimum inlet pressure should be 6" W.C. on natural gas and 11" W.C. on propane gas. The maximum inlet pressure for either gas is 14" W.C. If inlet pressure exceeds 14" W.C., a gas pressure regulator must be added upstream of the combination gas valve.
20. Open the field installed manual gas shut-off valve.
21. Open the manual main gas valve on the combination gas valve. Call for heat with the thermostat and allow the pilot to light for intermittent pilot ignition. If the pilot does not light, purge the pilot line. If air purging is required, disconnect the pilot line at outlet of pilot valve. In no case should the line be purged into heat exchanger. Check the pilot flame length (See Pilot Flame Adjustment).
22. Once the pilot has been established, check to make sure that the main gas valve opens. Check the manifold gas pressure (See Main Gas Adjustment) and flame length (See Air Shutter Adjustment) while the supply fan blower is operating.
23. Check to insure that gas controls sequence properly (See Control Operating Sequence). Verify if the unit has any additional control devices and set according to the instructions in the Control Options.
24. Once proper operation of the unit has been verified, remove any jumper wires that were required for testing.
25. Close the electrical compartment door.
26. Replace all exterior panels.


Pilot Burner Adjustment

The pilot burner is orificed to burn properly with an inlet pressure of 6-7" W.C. on natural gas and 11-14" W.C. on propane gas. Final adjustment must be made after installation. If the pilot flame is too long or large, it may cause soot and/or impinge on the heat exchanger causing failure. If the pilot flame is too short, it may cause poor ignition or result in the controls not opening the combination gas control. A short flame can be caused by a dirty pilot orifice. The pilot flame should be observed periodically to assure trouble-free operation.

To Adjust the Pilot Flame

1. Create a call for heat from the thermostat.
2. Remove the cap from the pilot adjustment screw. For location, see the combination gas control literature supplied with unit.
3. Adjust the pilot length by turning the screw in or out to achieve a soft steady flame 3/4" to 1" long and encompassing 3/8"-1/2" of the tip of the flame sensing rod (See Figure 16.1).
4. Replace the cap from the pilot adjustment screw.

Figure 16.1 - Correct Pilot Flame



START-UP PROCEDURE

Main Burner Adjustment


The gas pressure regulator (integral to the combination gas control) is adjusted at the factory for average gas conditions. It is important that gas be supplied to the duct furnace in accordance with the input rating on the serial plate. Actual input should be checked and necessary adjustments made after the duct furnace is installed. Over-firing, a result of too high an input, reduces the life of the appliance and increases maintenance. Under no circumstances should the input exceed that shown on the serial plate.

Check/Adjust Pressure at the Combination Gas Valve

This section applies to all units, regardless of gas control type.

1. Turn the field installed manual shut-off valve to "OFF".
2. Remove the 1/8" pipe plug in the pipe tee or gas valve and attach a U-tube type water manometer which is at least 12" high and capable of reading to 0.1" W.C. See Figure 17.1.
3. Turn the field installed manual gas shut-off valve to "ON".

Figure 17.1 - Checking Gas Pressure with Manometer



4. Create a high fire call for heat from the thermostat.
5. Determine the correct high fire manifold pressure, which depends on gas type and gas control type. Review the furnace Model Digit 11 and 12 (not the system model number) and adjust the main gas pressure regulator spring to achieve the proper manifold pressure as shown in Table 17.1. For location of regulator adjustment, refer to the combination gas control literature supplied with the unit.

Table 17.1 - Manifold Gas Pressure - Main Valve

Furnace Model Digit 11	Furnace Model Digit 12	Manifold Pressure
N (Natural)	1, 2, 4, 7, 8	3.5"
	9 ①	4.0"
P (Propane)	1, 2, 4, 7, 8	10.0"
	9 ①	10.5"

① For units with Model Digit 12=9 and multiple furnaces, only one furnace will be Model Digit 12=9, the additional furnaces will be Model Digit 12=2, therefore pressures will be different for those furnaces.

6. If the unit has Electronic Modulation gas controls (Model Identification Digit 12=4, 7, 8, or 9), skip steps 7 through 9 in this section and proceed to the next section "Check/Adjust Pressure for the Modulating Valve", otherwise continue to the next step.

7. After adjustment, move the field installed manual shut-off valve to the "OFF" position, remove the manometer, and replace the 1/8" pipe plug.
8. After the plug is in place, move the field installed manual shut-off valve to the "ON" position and recheck pipe plugs for gas leaks with soap solution.
9. Proceed to the section "Air Shutter Adjustment".

Check/Adjust Pressure for the Modulating Valve

This section only applies to units with Electronic Modulation gas controls (Model Identification Digit 12=4, 7, 8, or 9). Refer to the appropriate instructions for the valve type on the unit.


For Units with Model Digit 12=4, 7, or 8:

The low fire gas pressure needs to be adjusted. This needs to be repeated on each furnace in multiple furnace units. Using Figure 17.2 for item locations, this is accomplished as follows:

1. Disconnect power.
2. Remove all wires from Maxitrol Amplifier terminal "3" or duct furnace terminal "43" (if available).
3. Turn on power at the disconnect switch.
4. Remove the cover plate (2), maximum adjustment screw (4), spring (5), and plunger (8). A small magnet is useful for this purpose. CAUTION - The plunger is a precision part. Handle carefully to avoid marring or picking up grease and dirt. Do not lubricate.
5. Using minimum adjusting screw (9), adjust low fire manifold pressure to 0.56" W.C. for natural gas and 1.6" W.C. for propane gas.
6. Replace plunger and spring retainer, spring, and maximum adjusting screw in proper order.
7. Using maximum adjustment screw (4), adjust high fire manifold pressure to 3.5" W.C. for natural gas and 10" W.C. for propane gas.
8. Disconnect power.
9. Replace cover plate (2) and re-install all wires from Maxitrol amplifier terminal "3" or duct furnace terminal "43".
10. After adjustment, move the field installed manual shut-off valve to the "OFF" position, remove the manometer, and replace the 1/8" pipe plug.

(continued next page)

Figure 17.2 - Maxitrol Modulating Valve Adjustments



START-UP PROCEDURE

Check/Adjust Pressure for the Modulating Valve (continued)

11. After the plug is in place, move the field installed manual shut-off valve to the "ON" position and recheck pipe plugs for gas leaks with soap solution.
12. Proceed to the section "Air Shutter Adjustment".

For Units with Model Digit 12=9:


The high fire gas pressure needs to be adjusted first, followed by the low gas pressure. For multiple furnace units, this is only required on the duct furnace that has the modulating valve (Model Digit 12=9). This is accomplished as follows:

1. Verify the main valve (valve before the modulating valve) outlet pressure has been set to 4.0" W.C. for natural gas or 10.5" W.C. for propane gas per instructions and table 17.1 on the previous page. For multiple furnace units, the furnaces without the modulating valves are to remain at 3.5" W.C. for natural gas or 10.0" W.C. for propane gas. For location of regulator adjustment, refer to the combination gas control literature supplied with the unit.
2. The Maxitrol EXA modulating valve series has a cover secured with two screws that must be removed. Once removed, there are a bank of (3) DIP switches and two buttons and a communication LED for the user interface as shown in Figure 18.1.
3. Verify that the DIP switches are properly set to the "OFF" position for switches 1 and 3 and "ON" for switch 2.
4. Adjust the High Fire Setting as follows:
 - a. Enable the unit controls and create a call for heat.
 - b. Press and hold Button #1 on the modulating valve until the LED lights solid red, then release.
 - c. With the valve now in the high fire setting mode, confirm or adjust the high fire manifold pressure to be 3.5" W.C. If the pressure needs to be adjusted, press or hold Button #1 to increase gas flow and press or hold Button #2 to decrease gas flow.
 - d. If 3.5" W.C. cannot be attained, recheck the inlet gas pressure as described previously. After addressing any issues, if 3.5" W.C. still cannot be attained, step the valve closed using button #2 to the point where manifold pressure begins to be impacted. If the pressure at that point is less than 3.3" W.C., recheck your inlet pressure with the unit operating and adjust as required.
 - e. Save the setting by simultaneously holding Buttons #1 and #2 until the LED turns OFF. If this is not performed within 5 minutes, the control will default to the previously saved settings and return to normal operating mode.
4. Adjust the Low Fire Setting as follows:
 - a. Press and hold Button #2 on the modulating valve until the LED light blinks red, then release.
 - b. With the valve now in the low fire setting mode, confirm or adjust the low fire manifold pressure to be no less than the minimum shown on the furnace serial plate in the box called "Min. Manifold Pressure". If the pressure needs to be adjusted:
 - c. Press or hold Button #1 to increase gas flow and #2 to decrease gas flow. It is best to push and release button #2 to single step the valve to the minimum manifold pressure. Holding the button is likely to cause

the valve to close too far and lose flame.

- d. Save the setting by simultaneously holding Buttons #1 and #2 until the LED turns OFF. If this is not performed within 5 minutes, the control will default to the previously saved settings and return to normal operating mode.
5. Once the setting of the modulating valve has been completed, replace the valve cover removed earlier.
6. Move the field installed manual shut-off valve to the "OFF" position, remove the manometer, and replace the 1/8" pipe plug.
7. After the plug is in place, move the field installed manual shut-off valve to the "ON" position and recheck the pipe plug for gas leaks with soap solution.
8. Proceed to the section "Air Shutter Adjustment".

Figure 18.1 - Maxitrol EXA Modulating Valve



Air Shutter Adjustment

Proper operation provides a soft blue flame with a well-defined inner core. A lack of primary air will reveal soft yellow-tipped flames. Excess primary air produces short, well-defined flames with a tendency to lift off the burner ports. For both natural and propane gas, the air shutters can be adjusted to control the burner flame height. The air shutters can be accessed by reaching behind the manifold tee in Figure 17.1. The larger models may require the removal of the manifold (see Manifold Assembly Removal).

Adjusting the primary combustion air is achieved by resetting the primary air shutters (See Figure 54.2). Prior to flame adjustment, operate duct furnace for about fifteen minutes. The main burner flame can be viewed after loosening and pushing aside the gas designation disc on the side of the burner box.

1. To increase primary air, loosen the air shutter set screws and move the air shutters closer to the manifold until the yellow tipped flames disappear and a clean blue flame with a well defined inner cone appears.
2. To decrease primary air, move the air shutters away from the manifolds until flames no longer lift from burner ports, but being careful not to cause yellow tipping.
3. Re-tighten set screws after adjustment.


START-UP PROCEDURE

Blower Adjustments

All belt drive supply fan speed adjustments can be made with the adjustable sheave on the blower motor as follows:


1. Refer to page 38 to determine correct blower speed according to job requirements, then proceed to the next step.
2. Turn off power to the unit at the disconnect switch. If equipped with gas heat option, turn all hand gas valves to the "OFF" position.
3. Loosen the belt tension and remove the belt.
4. On the motor sheave, loosen the set screw on the side away from the motor (see Figure 19.1).

Figure 19.1 - Motor Sheave Adjustment



5. Turn outer side of motor sheave clockwise until motor sheave is fully closed.
6. From fully closed position, turn outer side of motor sheave counterclockwise until the proper number of turns open are achieved. Turns should be done in half-turns (180° rotations). Each half turn results in a change of blower speed and air volume of approximately 2.5-5%. Adjusting the half of the sheave inward increases blower speed, adjusting outward decreases blower speed.
7. Tighten the set screw on the flat portion of the motor shaft.
8. Replace the belt and verify that the belts are aligned in the sheave grooves properly and are not angled from sheave to sheave.

Figure 19.2 - Belt Tension Adjustment



9. Retighten motor base. Motor base should be shifted for proper belt tension which is 3/4" deflection with about 5 lbs. of force. Refer to Figure 19.2.
10. Turn on power to the unit and initiate blower motor operation. Do not fire gas controls until blower adjustment has been made or unit may cycle on high limit control.

11. Check the motor amps to ensure the maximum motor amp rating is not exceeded. Verify airflow volume and repeat steps above for further adjustment.
12. If equipped with gas heat, turn on the gas and initiate burner operation.
13. Verify the temperature rise and supply air temperature of the heating section do not fall outside the range or exceed the maximums shown in Table 32.1.
14. After 24 hours of operation, retighten the setscrews to the torque listed in the owners manual on the bearing, sheave, and blower wheel to avoid damage to the unit.

Lubrication Recommendations


The blower can be provided with either spider or pillow block bearings. Spider bearings are permanently lubricated and do not require lubrication. Pillow block bearings are shipped greased from the factory but will require lubrication. The bearings should be checked and lubricated before each heating season but a more frequent lubrication schedule may be required based on the environment in which the unit is installed, and the frequency of the equipment operation. Shell Alvania #2 lubricant is recommended.

Damper Linkage Adjustment

If the unit is provided with a return air damper, to prevent shipping damage, the return air damper linkage is disconnected and the damper closed. Before operating the unit, the fresh and return air dampers must be connected. This is accomplished by the following:

1. The damper actuator should be de-energized and the fresh air damper in a fully closed position.
2. Open the return air damper in a fully open position.
3. Slide the connecting rod into the ball joint on the blade arm with the return air damper fully open. See Figure 19.3.
4. Tighten the 5/16" hex head screw on the ball joint.

Figure 19.3 - Damper Linkage Adjustment



START-UP PROCEDURE

Furnace Control Operating Sequence

IMPORTANT

To prevent premature heat exchanger failure, with all control systems, a blower starting mechanism must be provided so that the blower is running or energized within 45 seconds of the gas control operation.

Furnaces are supplied with intermittent pilot systems with continuous retry, which both the main burner and pilot burner are turned off 100% when the thermostat is satisfied.

Control Options (see page 23) could change the listed sequence of operation for the unit based on their function. The descriptions given below are for the basic duct furnace.

Single Furnace Controls

Single furnace units (Model Digits 4-6=75 through 400) are offered with different types of gas control:

- **Staged Control (Model Digit 12=1 or 2):** These furnaces utilize a single- or two-stage combination gas valve, an ignition control, and a low voltage thermostat.
- **Electronic Modulating Control (Model Digit 12=4, 7, or 8):** These furnaces utilize a single-stage combination gas valve, an electronic modulating gas valve, a modulating amplifier, an ignition control, and one of the following:
 - » Modulating room thermostat
 - » Modulating duct thermostat with remote temperature set point adjuster
 - » Building Management System (BMS) signal by others (an inverted signal where 0VDC or 4mA is high fire and 10VDC or 20mA is low fire).
- **Electronic Modulating Control with Modine Control System (Model Digit 12=9):** These furnaces utilize a single-stage combination gas valve, an electronic modulating gas valve, a programmable microprocessor based controller, an ignition control, and different sensors depending on the application, but most commonly include:
 - » A duct temperature sensor
 - » A space temperature sensor
 - » There is also BMS integration capability for BACnet or LonWorks protocol systems.

The control operating sequence for all furnaces is as follows:

1. The thermostat calls for heat or is enabled by the BMS.
2. The power exhauster relay is energized starting the power exhauster motor. Once the motor has reached full speed, the differential pressure switch closes. The power exhauster pre-purge time delay relay then closes after 20 to 40 seconds and energizes the gas control circuit.
3. The pilot valve opens and the spark igniter sparks in an attempt to light the pilot. The system will attempt to light the pilot for 70 seconds. If the pilot is not sensed for any reason, the ignition control will wait for approximately six minutes with the combination gas control closed and no spark. After six minutes, the cycle will begin again. After three cycles, some ignition controllers lockout for approximately one hour before the cycle begins again. This will continue indefinitely until the pilot flame is sensed or power is interrupted to the system.

4. Once the pilot is lit, the flame sensor proves the pilot and stops the spark igniter from sparking.
5. The main gas valve is opened and the main burner is controlled as follows:
 - a. **Single-Stage Furnaces (Model Digit 12=1):** The main burner is lit to 100% full fire.
 - b. **Two-Stage Furnaces (Model Digit 12=2):** The main burner is lit to 50% fire. If the temperature at the thermostat continues to fall, the thermostat will call for high stage heat and the main burner is lit to 100% full fire.
 - c. **Modulating Room or Duct Thermostat (Model Digit 12=4):** The main gas valve is opened 100% and the burner firing rate is modulated between 40% and 100% full fire. A resistance signal (8000 to 12000 ohms) in the thermostat is converted by the modulating amplifier to an inverted DC voltage (between 0VDC for high fire to 12 VDC for low fire) and applied to the modulating gas valve to control the gas flow to the main burner.

Note: When modulating duct sensing is utilized, a room override thermostat can be added. When the room override calls for heat, the burner modulates to full fire operation until the room override is satisfied. The unit then reverts back to duct sensing control. When equipped with both, either the duct sensor or the room override thermostat can call for heat.
 - d. **BMS Signal (Model Digit 12=7 or 8):** The main gas valve is opened 100% and the burner firing rate is modulated between 40% and 100% full fire. A BMS 0-10VDC or 4-20mA signal (inverted, such that 0 VDC or 4 mA is high fire and 10 VDC or 20 mA is low fire) is converted by the signal conditioner/modulating amplifier into an inverted DC voltage (between 0VDC for high fire to 12 VDC for low fire) and applied to the modulating gas valve to control the gas flow to the main burner. The signal conditioner can accept a 0-10 VDC signal when all the dip switches are in the "OFF" position and 4-20 mA signal when all the dip switches are in the "ON" position.

Note: For further information regarding the operation of any of the electronic modulating system options above, consult the literature provided with the unit.
 - e. **Modulating with Modine Control System (Model Digit 12=9):** The main gas valve is opened 100% and the burner firing rate is modulated between 40% and 100% full fire. Heating demand is determined by the Modine Control System through a comparison of the supply air or space temperature to setpoint and a DC voltage (between 2VDC for low fire to 10 VDC for high fire) is applied to the modulating gas valve to control the gas flow to the main burner.

Note: Typically the temperature control is via supply air with the space sensor used to reset the supply air temperature setpoint. For additional information, refer to the Modine Control System Manual, literature #74-510 that shipped with the unit.
6. If the unit was provided with a time delay relay, the blower starts after 30 to 45 seconds.
7. Once the temperature is satisfied, both the main and pilot valves close 100%. Blower operation may or may not continue, depending on application.

START-UP PROCEDURE

Multiple Furnace Controls

Multiple furnace units are available as two furnace units (Model Digits 4-6=500 through 800) and three furnace units (Model Digits 4-6=840 or 960) and with different types of gas control:

- **Staged Control (Model Digit 12=1):** For control of multiple staged furnaces, each furnace would be individually controlled. Refer to the section for Single Furnace Controls, Staged Control (Model Digit 12=1).
 - » Two furnace units would be controlled as 2-stage (50%/50%).
 - » Three furnace units can be controlled as 3-stage (33%/33%/33%) or 2-stage (33%/67%).
- **Electronic Modulating Control (Model Digit 12=4):** For control of multiple electronic modulating furnaces, one furnace is the Primary furnace featuring a modulating amplifier capable of driving modulating gas valves on Secondary furnaces. Because all valves are driven by one amplifier, all valves modulate at the same rate, from 40% to 100% full fire. Refer to the section for Single Furnace Controls, Electronic Modulating Gas Controls (Digit 12=4).
- **Electronic Modulating Control (Model Digit 12=7 or 8):** For control of multiple electronic modulation furnaces for BMS control (0-10VDC or 4-20mA control signal), each furnace would be individually controlled. Refer to the section for Single Furnace Controls, Electronic Modulation Control (Model Digit 12=7 or 8).
- **Modulating with Modine Control System (Model Digit 12=9):** For control of multiple furnaces, one furnace features a modulating gas valve while additional furnaces are two stage furnaces. The Modine Control system seamlessly stages furnaces and modulates the primary furnace based on demand.

Variable Air Volume Applications

Units may be supplied with variable frequency drives for applications where variable air volume is required. The minimum air flow may be reduced to as low as 30% of the full speed air flow, but not lower than the minimum airflow listed in Table 21.1 and 32.1, unless certain conditions are followed. Refer to the following section titled "Extended VAV Airflow Limits" for additional information.

To determine the actual minimum allowable airflow, all unit selections must be performed with the AccuSpec configuration software. Within AccuSpec, multiple variable frequency drive speed control changeover options are available, which include these common selections:

- Two speed which may be controlled by a manual high/low switch which may be factory mounted on the control panel or shipped loose for field installation or by exhaust fan interlocks.
- Floating building pressure sensing which utilizes a Photohelic pressure controller to adjust the building pressure by varying the amount of makeup air supplied to the space.
- Building management control which allows for an external signal of 0-10VDC of 4-20mA to adjust the unit airflow.

Additional options are available when the unit is configured with the Modine Control System option (Model Digit 12=9).

Extended VAV Airflow Limits

If certain conditions are followed, the allowable minimum CFM of the system can be extended to:

- 75% of the minimum listed CFM in Table 32.1 for high air temperature rise units (Model Digit 10=H)
- 66% of the minimum listed CFM in Table 32.1 for low air temperature rise units (Model Digit 10=L).

Refer to Table 21.1 for a summary of the reduced minimum airflows, indicated in the column "Extended Range". To allow the reduced airflows, the unit must be applied as follows:

1. The unit has 2-stage or modulating gas controls.
2. The unit is provided with a discharge air thermostat.
3. The system does not include a room thermostat.
Exception: See note below for units equipped with the Modine Control System option (Model Digit 12=9).

The discharge air thermostat will prevent the unit from firing above the allowable 100°F rise when the unit is at or above the minimum CFM by monitoring the discharge air and going to low fire. A room thermostat, because it is located remote from the unit, could cause the unit to over-fire.

Note for units equipped with the Modine Control System option (Model Digit 12=9): A space temperature sensor (Carel pAD) is permitted, as a call for heating from the space results in a reset of the supply air temperature setpoint that will still maintain a supply temperature that is at or below the maximum allowable discharge air temperature.

Table 21.1 - Extended Range VAV Minimum Airflow

Input Rating (Digit 4-6)	Minimum Airflow (CFM)			
	High ATR (Digit 10=H)		Low ATR (Digit 10=L)	
	Standard	Extended Range ①	Standard	Extended Range ②
75	563	422	938	619
100	750	563	1,250	825
125	938	703	1,563	1,031
150	1,125	844	1,875	1,238
175	1,313	984	2,188	1,444
200	1,500	1,125	2,500	1,650
225	1,688	1,266	2,813	1,856
250	1,875	1,406	3,125	2,063
300	2,250	1,688	3,750	2,475
350	2,625	1,969	4,375	2,888
400	3,000	2,250	5,000	3,300
500	-	-	3,125	2,063
600	-	-	3,750	2,475
700	-	-	4,375	2,888
800	-	-	5,000	3,300
840	-	-	6,562	4,331
960	-	-	7,500	4,950

① Extended range minimum can be 75% of standard minimum.

② Extended range minimum can be 66% of standard minimum.


Cooling Coil Operation

1. Airflow must be properly distributed across the coil face and should not vary by more than 20%.
2. Air velocities should be maintained between 200 and 550 feet per minute. Refer to Figure 15.1.
3. For chilled fluid coils, fluid velocities should be maintained within the recommended values of 1 to 8 feet per second (fps) for Water and 1 to 6 fps for Glycol solutions.

COMPONENT/OPTION LOCATIONS

For location of standard and optional factory installed components, refer to Figure 22.1 and the descriptions on the following pages.

Figure 22.1 - Factory Mounted Option Locations



COMPONENT DESCRIPTIONS

All units include the standard (STD) features. The unit must be reviewed to determine the optional (OPT) features that may have been supplied with the unit. Refer to Figure 22.1 for the descriptions on the following pages.


(1) Discharge Thermostat/Sensor – (OPT)

The discharge thermostat or sensor is field installed in the discharge (supply) air ductwork. For additional information, refer to the thermostat vendor literature provided in the literature packet with the unit. Model Sizes 500-960 contain multiple furnaces so multiple thermostats/sensors may be included.

The thermostat(s) provided can be one of the following:

a. Two-Stage Capillary Thermostat (Digit 12=1 or 2)

The thermostat capillary is to be field routed/installed in the ductwork. The thermostat body contains the setpoint adjuster that must be field set.



b. Two-Stage Electronic Thermostat (Digit 12=1 or 2)

The thermostat body is field installed remotely and includes the discharge air set point adjuster that must be field set. Refer to Literature 5-577 latest revision.



c. Electronic Modulating Discharge Sensor (Digit 12=4)

Includes a field installed mixing tube and discharge air sensor field installed in duct work. The set point adjuster is field installed remotely and must be field set. Refer to Literature 5-578 latest revision for instructions.



d. Supply Air Sensor (Model Digit 12=9) (not shown)

Used on units with Modine Control System option, the sensor includes either a fixed or adjustable length sensor field installed in duct work. Refer to Literature 74-541 latest revision for instructions.

(2) Low Gas Pressure Switch – (OPT)

The switch monitors the gas pressure upstream of all the gas controls and disables the ignition controller and combination gas valve if low gas pressure is experienced. The switch is automatic reset, allowing the unit to operate when gas pressure returns above the minimum setpoint. The switch should be set to insure that the minimum inlet gas pressure is available (6" W.C. for natural gas, 11" W.C. for propane gas).

(3) High Gas Pressure Switch – (OPT)

The switch monitors the gas pressure downstream of all the gas controls and disables the ignition controller and combination gas valve if high gas pressure is experienced right before the manifold. The switch is manual reset so that if the gas pressure is too high, a service person must check the unit to be sure the gas controls have not been damaged, then reset the switch to allow the unit to operate when gas pressure returns below the maximum setpoint. The switch should be set to insure that the maximum manifold gas pressure is not exceeded (3.5" W.C. for natural gas, 10" W.C. for propane gas).

Low and High Gas Pressure Switches



(4) Duct Furnace Power Exhauster – (STD)


The power exhauster, on a call for heat, creates a combustion draft through the duct furnace prior to the pilot being energized. The draft is proven through the power exhauster motor centrifugal switch that closes when the motor reaches full speed. The unit door includes a power exhauster discharge cover and inlet combustion louvers. For information about venting, refer to the Installation – Venting section.

(5) Timed Freeze Protection (OPT) (All Except Digit 12=9)

The timed freeze protection system includes a sensor factory installed in the discharge air stream. On initial start-up, the timed delay in the system allows the unit to go through the normal ignition sequence. The timed delay is a manual reset switch and adjustable for 1-10 minutes. In the event that the unit fails to fire after this period, the discharge air sensor will sense the cold air (30°-75°F adjustable) and will shut down the unit.

For units with the Modine Control System option (Model Digit 12=9), this feature is integral to the control logic and utilizes existing sensors included with that option. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

Timed Freeze Protection Module



COMPONENT DESCRIPTIONS

(6) Ignition Controller – (STD)

The ignition controller is factory installed in the duct furnace electrical junction box with the spark ignitor and sensor located on the burner. For both natural and propane gas units, the ignition controller is 100% shut-off with continuous retry. On a call for heat, the system will attempt to light the pilot for 70 seconds. If the pilot is not sensed for any reason, the ignition control will wait for approximately six minutes with the combination gas control closed and no spark. After six minutes, the cycle will begin again. After three cycles, some ignition controllers lockout for approximately one hour before the cycle begins again. This will continue indefinitely until the pilot flame is sensed or power is interrupted to the system.

(8) Control Relay – (OPT)

The control relay(s) are factory installed in the duct furnace electrical junction box. The relay has a 24V coil with double-pole, double throw (DPDT) contacts. Refer to the unit wiring diagram for the switching function of the relay. The two normally open and two normally closed contacts are rated for a maximum of 30 amps @ 115V/1Ph.

(9) Time Delay Relay – (STD)

The time delay relay is factory installed in the duct furnace electrical junction box. The time delay relay allows the gas controls to operate for approximately 30 seconds before the blower starts. This allows the heat exchanger a warm up period so that the initial delivered air is not cold. The time delay relay also keeps the motor running for approximately 30 seconds after the call for heat has been satisfied to remove the residual heat from the heat exchanger. For single phase units below 1-1/2 Hp, the time delay relay controls the motor directly. For single phase units 1-1/2 Hp and greater and all three phase units, the time delay relay controls the motor starter.

(10) Furnace Low Voltage Terminal Strip – (STD)

The terminal strip is labeled to match the electrical wiring diagram provided with the unit. All field wiring connections should be made to the top side of the terminals to prevent miswiring by modifying the factory wiring which is made to the bottom of the terminal strip.

(11) Power Exhaust Relay – (STD)

The control relay is factory installed in the duct furnace electrical junction box. On a call for heat, the relay coil is energized resulting in the contacts energizing the power exhauster motor.

(12) Furnace Supply Power Terminal Strip – (STD)

The terminal strip is labeled to match the electrical wiring diagram provided with the unit. All field wiring connections should be made to the bottom side of the terminals to prevent miswiring by modifying the factory wiring which is made to the top of the terminal strip.

(13) Control Step Down Transformer – (STD)

The control step down transformer is located in the duct furnace electrical junction box. The transformer is used to step down the supply power (115V, 208V, 230V, 460V, 575V) to 24V for the gas controls, damper actuator, relays, etc. Refer to Model Digit 15 of the unit model nomenclature to determine the volt-amp (VA) capacity of the transformer.

(14) Control Relay – (OPT)

The control relay is factory installed in the blower electrical section. See description of Option 8 for additional details.

(15) Blower Low Voltage Terminal Strip – (STD)

The terminal strip is labeled to match the electrical wiring diagram provided with the unit. All field wiring connections should be made to the right side of the terminals to prevent miswiring by modifying the factory wiring which is made to the left side of the terminal strip.


(16) Dead Front Disconnect Switch – (OPT)

! WARNING

When the dead front disconnect switch is in the "OFF" position, supply power remains energized at the blower supply power terminal strip and the top of the dead front disconnect switch. When providing service on or near these terminals, building supply power to the unit should be de-energized.

The dead front disconnect switch is factory installed in the blower electrical section. The disconnect switch is designed so that it must be turned "OFF" before entry to the electrical control cabinet can be obtained (see Figure below). When in the "OFF" position, power is disconnected to all unit wiring electrically following the switch (See Warning). For servicing the unit, the disconnect switch can be manually overridden by using a wrench and turning the disconnect switch shaft 90° clockwise. Fusible and circuit breaker switches available. For fusible switches, Class "J" time delay fuses must be field provided matching the fuse size listed on the Model Identification plate.

Figure 24.1 - Dead Front Disconnect Switch Assembly



COMPONENT DESCRIPTIONS

(17) Step Down Transformer Fuses – (OPT)

The transformer fuses are factory installed in the blower electrical section. The fuses are included to protect the transformer.

(18) Step Down Transformer – (OPT)

The step down transformer is factory installed in the blower electrical section. The transformer is required as follows:

Without Evap Cooler (Model Digit 22=0)

- Supply voltage of 460V/3Ph or 575V/3Ph (Model Digit 14=F or G). The transformer reduces the voltage to 115V for the power exhausters(s).

With Evap Cooler (Model Digit 22=D)

- Supply voltage of 208V/1Ph or 208V/3Ph (Model Digit 14=B or D). The transformer reduces the voltage to 115V for the evaporative cooler. The power exhausters(s) will be 208V.
- Supply voltage of 460V/3Ph or 575V/3Ph (Model Digit 14=F or G). The transformer reduces the voltage to 115V for the power exhausters(s) and evaporative cooler.

For all other configurations, the transformer is not required.

(19) Minimum Positioner – (OPT) (All Except Model Digit 12=9)

The factory installed minimum positioner is installed in the blower electrical section and is used with a modulating damper actuator to set the minimum percentage of outside air. The minimum positioner dial is manually set between 0 to 100% resulting in a 2 to 10 VDC signal being sent to the damper actuator. When used in conjunction with the Proportional Temp Controller, the positioner sets the minimum outside air percentage and the Proportional Temp Controller then modulates between the minimum position and 100% outside air.

For units with the Modine Control System option (Model Digit 12=9), this feature is available as a damper control when configured properly and does not require a separate additional positioner. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

Figure 25.1 - Minimum Positioner



(20, 21) Extended Grease Lines – (OPT)

The extended grease lines (21) are factory installed in the blower section and include Zerk® grease fittings (20) factory installed on the exterior corner post between the electrical and blower sections. This option allows the pillow block bearings to be lubricated with a grease gun without requiring the service personnel to remove both blower doors to access the bearings. Refer to Lubrication Recommendations for additional information.

(22) Return Air Fire Stat – (OPT)

The return air fire stat is factory installed in the blower electrical section with the sensor in the return air stream. In case of elevated temperatures at the sensor, the manual reset switch shuts down the entire unit. If the limit temperature is exceeded, a service person must inspect the unit for the cause of the high temperature, take corrective action, and then reset the switch.

(23) Blower Housing – (STD)

The blower section contains a double width, double inlet (DWDI) blower wheel. Both sides of the blower must be free from obstructions for proper operation. For Right Hand units (Model Digit 9 = R), during operation the blower wheel should rotate in the clockwise direction when viewed from the service side of the unit. For Left Hand units (Model Digit 9 = L), the blower wheel should rotate in the counterclockwise direction when viewed from the service side of the unit. If necessary, interchange supply power wiring to reverse blower rotation.

(24) Pillow Block Bearings – (OPT)

The blower can be provided with either spider or pillow block bearings. Spider bearings are permanently lubricated and do not require lubrication. Pillow block bearings are shipped non-greased from the factory and require lubrication before start-up. For lubrication recommendations, see Lubrication Recommendations.

(25) Blower Motor – (STD)

The blower motor can be provided in a variety of supply voltages, frame types, and motor horsepower. Refer to the model nomenclature to determine the type of motor provided. The blower motor is supplied with an adjustable sheave that can be used to increase/decrease the blower RPM. For instructions on changing the blower RPM, refer to Blower Adjustments.

(26) Filters – (OPT)

When filters are supplied with the unit, a rack and the filters are factory installed in the blower section. The unit can be supplied with 2" permanent filters, 2" pleated throwaway filters in MERV 8 or 13 ratings. For filter replacement, refer to Maintenance.

(27) Fresh Air Damper – (OPT)

When a fresh air damper is supplied with the unit, the damper is used as an outside air shut-off damper. The damper is ultra low leak, Class II leakage resistance (less than 10 CFM/ft² at 1" W.C.) dampers with self-compensating stainless steel side seals and santoprene and galvanized steel blade seals.

(29) Rainhood and Birdscreen – (OPT)

The rainhood and birdscreen is shipped loose for field installation at the back of the blower section. For installation instructions, refer to Literature 5-589, latest revision.

COMPONENT DESCRIPTIONS

(30) Direct Drive Damper Actuator – (OPT)


The direct drive damper actuator is factory installed on the side of the fresh air damper. The return air damper, if provided, is controlled by the damper linkage between the two dampers. All damper actuators are low voltage (24V). For Right Hand units (Model Digit 9 = R), during operation the actuator should rotate in the counterclockwise direction when viewed from the service side of the unit. For Left Hand units (Model Digit 9 = L), the actuator should rotate in the clockwise direction when viewed from the service side of the unit. Three different types of dampers actuators can be provided: Two-Position, Modulating, and Floating.

- **Two-Position Damper Actuator:** A two-position actuator is provided with Air Control options (Model Digits 20-21=DA and EA). The actuator provides open/closed operation of the fresh air damper. When the actuator is energized, the fresh air damper is opened to 100% outside air in 75 seconds (for outside air percentages lower than 100%, refer to the following section, "Setting the Damper Limiter"). Actuators are spring return, so when the damper is de-energized, the fresh air damper will spring closed. Actuator include auxiliary switches (one normally open and one normally closed) that reverse when the damper actuator is at 85° rotation (adjustable).

Setting the Damper Limiter: The two-position damper limiter can be factory set to prevent the outside air damper from opening 100%. Field adjustment of the two-position damper limiter is accomplished by the following:

1. Determine the maximum outside air % required.
2. Locate the angle of rotation limiter on the actuator so that its edge lines up with the degree graduation on the actuator face corresponding to the required rotation. (See figure below which is shown at 50% rotation limit.)
3. Position the limiter to the desired position, making sure the locating "teeth" on the limiter are engaged into the locating holes on the actuator.
4. Fasten the limiter to the actuator using the screw provided.
5. Test the damper rotation either manually with the manual crank or apply power. Re-adjust if necessary.
6. If the damper end switch is being used in the control circuit and needs to be adjusted for the new limit position, refer to the next section, "Adjusting the Damper End Switch".


Figure 26.1 - Two-Position Damper Actuator Limiter



Adjusting the Damper End Switch: If the damper limiter was adjusted in the previous section, it may be required to adjust the Damper End Switch as follows:

1. The actuator must be in its fail-safe position.
2. Insert the crank handle into the Torx shaped hole in the center of the adjustable switch pointer as shown below.
3. Gently rotate the crank until the switch pointer is at the desired switch point in degrees as shown.

Figure 26.2 - Adjusting the Damper End Switch



- **Modulating Damper Actuator:** A modulating actuator is provided with Air Control options (Model Digits 20-21=GA, GB, GC, GD, GE, GG, GH, and GJ). The actuator provides incremental operation of the fresh air damper (the return air damper is controlled by the fresh air damper position). Full 90° rotation of the actuator requires 150 seconds. Actuators operate using a 0-10 Vdc input signal (Air Control GB utilizes a resistor to convert from a 4-20 mA to 0-10 Vdc) from a damper controller. Actuators are spring return, so when the damper is de-energized, the fresh air damper will spring closed.

For units with the Modine Control System option (Model Digit 12=9), when the damper control is modulating, Model Digits 20-21 will always be GA and the control will be integral to the Modine Control System control logic. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

- **Floating Damper Actuator (All Except Model Digit 12=9):** A floating actuator is provided with Air Control option (Model Digits 20-21=HP). The actuator provides forward and reversing damper operation in response to contact closures from the space pressure controller. When above the desired high pressure setpoint, a contact on the space pressure controller energizes the actuator to drive the fresh air damper closed. When below the desired low pressure setpoint, a contact on the space pressure controller energizes the actuator to drive the fresh air damper open. When the space pressure is between the high and low setpoints, the damper remains at the fresh air percentage that satisfied the space pressure controller. Full 90° rotation of the floating actuator requires 150 seconds. For additional information on the space pressure controller, refer to Literature 5-585.

The actuator is designed to "float" and therefore is not spring return. When the unit is de-energized under normal operation, the fresh air damper is powered closed. If the supply power to the unit is interrupted before the damper actuator can drive closed, the fresh air damper will remain open.

COMPONENT DESCRIPTIONS

(31) Enthalpy Controller – (OPT) (All Except Model Digit 12=9)

An enthalpy controller is provided with Air Control option (Model Digits 20-21=GJ). The purpose of the enthalpy controller is to use outside air for free cooling, whenever possible, to reduce compressor operation of the mechanical cooling system. The economizer functions as a true first stage of cooling and minimizes energy usage during the cooling cycle.

The components used for the Enthalpy Economizer are:

- **Enthalpy Economizer Controller.** The controller is used in conjunction with the Enthalpy Sensor and a Mixed Air Temperature sensor. The controller is factory mounted in the blower control cabinet.
- **Outside Air Enthalpy Sensor.** The sensor provides a signal in relation to enthalpy (temperature and humidity) of the outside air and is installed in the outside air stream.
- **Mixed Air Temperature Sensor.** The sensor is factory installed in the blower section to sense the mixed air temperature of the fresh and return air streams.

For complete details on the Enthalpy Economizer controller setup and sequence of operation, please refer to Literature 5-598, latest revision.

Figure 27.1
Enthalpy Controller (Model Digits 20-21=GJ Only)



For units with the Modine Control System option (Model Digit 12=9), when the damper control is enthalpy economizer, Model Digits 20-21 will always be GA and the control will be integral to the Modine Control System control logic. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

(32) Damper to Damper Linkage – (OPT)

Units with fresh and return air dampers include a damper actuator that controls the fresh air damper. The return air damper position is controlled by the fresh air damper through the connecting rod. For adjustment, refer to Damper Linkage Adjustment.

(33) Return Air Damper – (OPT)

When a return air damper is supplied with the unit, the damper is factory installed in the blower section. The return air damper is used as an air balancing damper so low leak, Class III leakage resistance (less than 40 CFM/ft² at 1" W.C.) dampers with self-compensating stainless steel side seals and santoprene blade seals are used.

(34) Proportional Temperature Controller – (OPT) (All Except Model Digit 12=9)

A proportional temperature controller sensor is provided with Air Control options (Model Digits 20-21=GG or GH) and factory installed in the blower section. The sensor provides the mixed air temperature signal to the A350P Proportional Temperature Controller which is mounted in the electrical section. The controller sends a 2-10 Vdc signal to the modulating damper actuator in order to maintain the setpoint of the mixed air. The controller includes a set point dial that must be field set to the desired mixed air temperature (typically 55°F). This acts as a dry bulb economizer, primarily by utilizing warmer outside air as first stage heating to minimize gas heat energy usage.

Figure 27.2 - Proportional Temperature Controller




For units with the Modine Control System option (Model Digit 12=9), when the damper control is dry economizer, Model Digits 20-21 will always be GA and the control will be integral to the Modine Control System control logic. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

(35) Motor and Blower Vibration Isolation – (STD)

The motor vibration isolation is factory installed below the blower support bracket. The four (4) neoprene vibration mount grommets provide isolation of the blower housing and motor from the blower support channels. The blower duct connection is not rigidly mechanically fastened and the 1/4" thick gasketing around the duct transition provides vibration isolation.

Figure 27.3 - Blower/Motor Vibration Isolation



(36) Blower Support – (STD)

The blower supports are factory installed in the blower section. The blower supports are used to rigidly support the weight of the blower and motor during operation and shipping.

COMPONENT DESCRIPTIONS

(37) Convenience Outlet – (OPT)

The convenience outlet is factory installed in the blower section for providing power for 115V service equipment (trouble light, power tools, etc.). The 115V ground fault circuit interrupter (GFCI) is rated for 15 amps and includes test and reset switches. A separate field supplied 115V/1Ph power supply must be routed through the electrical section wall into the back of the

! WARNING


Do not perform service on the convenience outlet without disconnecting its power supply. The convenience outlet power supply is separate from main power supply to the unit. When the main disconnect switch is de-energized, the convenience outlet power supply remains energized.

convenience outlet junction box.

(38) Blower Door Switch – (OPT)

The blower door switch is installed inside the blower section door on the access side of the unit. If the door is removed, the switch interrupts power to the low voltage circuit. For single phase units 1-1/2 Hp and less, the switch de-energizes a relay that controls blower motor operation. For three phase units and single phase units 1-1/2 Hp and greater, the switch de-energizes the motor starter that controls blower motor operation. For servicing, the switch has an override position that can be manually pulled out to override the switch as shown below. For units with Modine Control System option (Model Digit 12=9), the switch is wired to a digital input on the unit controller.

Figure 28.1 - Blower Door Switch with Manual Override



(39) Dirty Filter Switch – (OPT)

The dirty filter pressure switch is factory installed in the blower electrical section. The switch monitors the pressure differential between the two sides of the filters. When the filters become dirty, the differential pressure increases and trips the pressure switch which energizes a light on the remote monitoring panel (for units with Modine Control System option (Model Digit 12=9), the switch is wired to a digital input on the unit controller). The switch must be field set with ductwork installed and the blower in operation.


Setting the Dirty Filter Switch

The range of the switch is adjustable between 0.17" to 5.0" W.C.

1. Ensure that the unit filters are clean or replace if necessary.
2. Connect leads of a continuity tester to the NO and C terminals of the pressure switch. See the figure below.
3. Turn the set screw of the pressure switch clockwise until it stops. This will set the pressure at 5.0" W.C. and the continuity tester should be sensing an open circuit.
4. Begin turning the screw counterclockwise until the continuity tester senses a closed circuit. This determines the base pressure of the system.
5. Turn the screw clockwise until the continuity tester senses an open circuit and then one additional full turn (This is approximately 0.25" W.C.) This will allow for the increase in static pressure due to dirty filters.

Figure 28.2

Dirty Filter Pressure and/or Air Flow Proving Switch



COMPONENT DESCRIPTIONS

(40) Motor Starter – (OPT)

The motor starter is factory installed in the blower electrical section. A motor starter is required for:

- All three phase motors
- Single phase motors 1-1/2 Hp and greater


If the factory installed motor starter option was not ordered with a unit that requires it, a motor starter must be field supplied and installed. Alternatively for three phase motors, see also the Variable Frequency Drive option below.

The overload module of the motor starter is designed to protect the motor from exceeding the nameplate amps. If the motor exceeds the amp draw on the current set point dial, the trip condition is indicated by a red color in the trip indicator window. The current set point dial is factory set to the motor full load amps listed on the motor nameplate.

The motor starter can be placed in the automatic or manual reset positions. Automatic reset is accomplished by depressing the "RESET" button and turning the button 1/4 turn. When in the automatic reset position, if the overload module trips, the module will reset itself once the overload relay has cooled. In the manual reset position, if the overload module trips, the "RESET" button must be depressed before the blower can operate.

The contactor module includes one (1) normally open auxiliary contact. The contact rating is 10 amps.

Figure 29.1 - Motor Starter



(40) Variable Frequency Drive – (OPT)

The VFD controller adjusts the motor rpm to vary the unit air flow. The minimum air flow may be varied between 30 and 100% of the full speed air flow depending on the controls selection of the unit (refer to the section "Variable Air Volume Applications" on page 21 for additional information).

The control changeover options include two speed, building pressure control, and building management control. For units with the Modine Control System option (Model Digit 12=9), additional control options may be available. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

(41) Mild Temperature Stat – (OPT) (All Except Digit 12=9)

The mild temperature thermostat is factory installed in the blower electrical section. The mild temperature thermostat is designed to lockout the burner during mild weather conditions which prevents the burner from cycling. The thermostat must be field set to the desired mild temperature condition (refer to the latest revision of Modine Literature 75-540).

For units with the Modine Control System option (Model Digit 12=9), this feature is integral to the control logic and utilizes existing sensors included with that option. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

(42) Proportional Temperature Controller – (OPT)

Refer to description for item # 40.

(43) Warm-Up Stat – (OPT) (All Except Model Digit 12=9)

A warm-up stat can be provided with Air Control options (Model Digits 20-21=EA, GG, or GH) and factory installed in the blower electrical section with the sensor in the return air stream. The warm-up thermostat monitors the return air temperature upon changing to the occupied mode and prevents the fresh air dampers from opening until the temperature of the return air has reached the desired set point (typically 65°F or 5°F below the room temperature).

(44) Blower Supply Power Terminal Strip – (STD)


The terminal strip is labeled to match the electrical wiring diagram provided with the unit. All field wiring connections should be made to the bottom side of the terminals to prevent miswiring by modifying the factory wiring which is made to the top of the terminal strip.

(45) Service Switches – (OPT) (All Except Model Digit 12=9)

The service switches are factory installed in the blower electrical section. The service switches allow for service personnel to independently test operation of the damper, blower, and furnace without using jumper wires. The switches override the remote monitoring panel and/or thermostats to energize each component directly. All switches need to be reset to the "OFF" position after testing otherwise the components will remain energized.

For units with the Modine Control System option (Model Digit 12=9), this feature is integral to the control logic and provides service personnel with real-time operating status of the unit systems. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

Figure 29.2 - Service Switches



COMPONENT DESCRIPTIONS

(46) Electronic Modulation Amplifier – (OPT)

An electronic modulation amplifier is provided factory installed in the duct furnace electrical junction box when the unit is equipped with Electronic Modulating Gas Controls (Model Digit 12=4). The amplifier processes the thermostat temperature and set point signals to modulate the firing rate between 40% to 100% full fire. For additional information, refer to Control Operating Sequence.

(47) Electronic Modulating Gas Valve – (OPT)

An electronic modulating gas valve is provided factory installed in the duct furnace gas train when the unit is equipped with Electronic Modulating Gas Controls (Model Digit 12=4, 7, 8, or 9). The gas valve modulates the firing rate between 40% to 100% full fire based on the input signal from the Electronic Modulation Amplifier (Model Digit 12=4), Signal Conditioner (Model Digit 12=7 or 8), or Modine Control System controller (Model Digit 12=9). For additional information, refer to the Furnace Control Operating Sequence section in this manual.

(48) Air Flow Proving Switch – (OPT)

The air flow proving switch is factory installed in the duct furnace electrical junction box. The air flow proving switch monitors the pressure differential between the duct furnace and the atmosphere. The purpose of the air flow proving switch is to cut power to the gas controls if a positive pressure is not measured by the switch. This could be caused by a lack of air movement through the heat exchanger.

NOTE: The air flow proving switch will prevent any heat exchanger warm-up because the gas controls can not be energized until air flow is proven.

Setting the Air Flow Proving Switch

The range of the switch is adjustable between 0.17" to 5.0" W.C.

1. Set the thermostat or controller so that there is a call for heat. For units with the Modine Control System option (Model Digit 12=9), refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.
2. Turn the set screw of the pressure switch clockwise until it stops. This will set the pressure at 5.0" W.C.
3. Turn the screw counter-clockwise until the gas controls light and then one additional full turn. This will allow for dirty filters or other slight system static pressure increases.

(49) High Limit Switch

The high limit switch is factory installed in the duct furnace electrical junction box. If the limit temperature is exceeded, the gas controls are de-energized. Two types of high limit switches are offered:

- **Automatic – (STD):** The automatic reset high limit will reset when the switch is cooled.
- **Manual – (OPT):** The manual reset high limit switch is factory installed in place of the standard automatic reset high limit switch. In case of a failure of the blower motor, blockage of the inlet air, etc., the manual reset switch prevents the unit from cycling on the high limit. If the limit temperature is exceeded, a service person must inspect the unit for the cause of the high temperature, take corrective action, and then reset the switch.

(50) Supply Air Fire Stat – (OPT)

The supply air fire stat is factory installed in the duct furnace electrical junction box with the sensor in the discharge air stream. In case of elevated temperatures in the supply air stream, the manual reset switch shuts down the entire unit. If the limit temperature is exceeded, a service person must inspect the unit for the cause of the high discharge temperature, take corrective action, and then reset the switch.

(51) Main Gas Valve – (STD)

The main gas valve is factory installed in the duct furnace gas train. The main gas valve provides the pilot, regulator, main gas, and manual shutoff functions. For additional information, see the supplier literature included with the unit.

(52) Burner Box – (STD)

The burner box is located in the duct furnace section and contains the burner and pilot assembly. The burner box includes an access panel for removal of the burner for inspection and servicing.

(53) Direct Drive Discharge Damper Actuator – (OPT)

The direct drive damper actuator is factory installed on the side of the discharge damper (available as an option on units with Model Digit 2=D or P). All discharge damper actuators are low voltage (24V), two-position, spring return type. For Right Hand units (Model Digit 9 = R), during operation the actuator should rotate in the counterclockwise direction when viewed from the service side of the unit. For Left Hand units (Model Digit 9 = L), the actuator should rotate in the clockwise direction when viewed from the service side of the unit.

The actuator provides open/closed operation of the discharge air damper. When the actuator is energized, the damper is opened to 100% outside air in 75 seconds. Actuators are spring return, so when the damper is de-energized, the air damper will spring closed. Actuator include auxiliary switches (one normally open and one normally closed) that reverse when the damper actuator is at 85° rotation (adjustable). When the damper is closed, the unit is not operating.

(54) Discharge Damper – (OPT)

When a discharge air damper is supplied with the unit, the damper is factory installed in the downturn plenum section. The discharge air damper is used an outside air shut-off damper so ultra low leak, Class II leakage (less than 10 CFM/ft² at 1" W.C.) dampers with self-compensating stainless steel side seals and santoprene and galvanized steel blade seals are used.

COMPONENT DESCRIPTIONS

(Not Shown) Circuit Analyzer – (OPT) (All Except Digit 12=9)

The circuit analyzer is factory installed on the door of the electrical section. The circuit analyzer is used to quickly assist service personnel in troubleshooting by monitoring the unit firing sequence and vital operating steps. Lights will come on as a point of electrical operation is passed and proven. If any light is not lit, that is the point where failure occurred.

For units with the Modine Control System option (Model Digit 12=9), this feature is integral to the control logic and provides service personnel with real-time operating status of the unit systems. Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

Figure 31.1 - Circuit Analyzer ①



① Circuit Analyzer tagging will vary based on the unit ordered. Circuit analyzer shown is for reference only.

For Modine Control System Units Only (Model Digit 12=9)

The following items may be included with units configured with the Modine Control System option:

(56) Carel pCOOEM+ Microprocessor Controller

The Modine Controls System utilizes a Carel pCOOEM+ programmable microprocessor controller that is factory installed in the duct furnace electrical section.

(57) Carel pLDPro User Interface Panel

The interface allows a user to access the Carel controller for setpoint changes and to view the operational status of the equipment. The interface features an LED backlit graphic display and buttons for excellent visibility.

(58) Control Relays - (OPT)

The control relay(s) are factory installed in the duct furnace electrical junction box. The relay has a 24V coil with double-pole, double throw (DPDT) contacts. Refer to the unit wiring diagram for the switching function of the relay. The two normally open and two normally closed contacts are rated for a maximum of 8A @ 230V/1Ph.

(59) Unit Enable Relay - (OPT)

The control relay is factory installed in the duct furnace electrical junction box and is used to enable the unit based on contact closure from a customer enable circuit. The closing of that contact will power a 24V relay from the unit mounted controller and enable the unit in On or Occupied mode. The relay provides electrical isolation to the controller for protection.

(60) Wiring Channels with Cover - (STD)

The wiring channels organize and separate high voltage and low voltage wiring.

(61) Return Air Sensor (not shown) - (OPT)

This sensor is required on all units that have a mixture of outside and return air. The sensor is field mounted in the return air ductwork. It may be dry bulb only or enthalpy (temperature and humidity).

(62) Outside Air Sensor (not shown) - (OPT)

This sensor is required on all units except 100% return air units and is field installed. Depending on the unit configuration, the sensor may be duct mounted or remote mounted. It may be dry bulb only or enthalpy (temperature and humidity).

(63) Mixed Air Sensor (not shown) - (OPT)

This sensor is required on all units that have a mixture of outside and return air and is factory mounted in the blower cabinet. The sensor is dry bulb temperature only.

Refer to the latest revision of the Modine Control System Manual, literature 74-510 for additional information.

GENERAL PERFORMANCE DATA

Table 32.1 - General Performance Data

Model Size (Digits 4-6)	Btu/Hr Input ①	Btu/Hr Output ①	Blower Style/Size		Minimum CFM ②	Maximum CFM	Temperature Rise (°F)	
			(Digit 16)	Size			Maximum	Minimum
75	75,000	60,750	A or B	9-7	562	1800	100	31
			C or D	9-9	750	2813	75	20
100	100,000	81,000	C or D	9-9	750	3000	100	25
			E or F	12-12	1500	3750	50	20
125	125,000	101,250	C or D	9-9	937	3000	100	31
			E or F	12-12	1500	4688	63	20
150	150,000	121,500	C or D	9-9	1125	3000	100	38
			E or F	12-12	1250	5550	90	20
175	175,000	141,750	C or D	9-9	1312	3000	100	44
			E or F	12-12	1312	5550	100	24
200	200,000	162,000	C or D	9-9	1500	3000	100	50
			E or F	12-12	1750	5000	86	30
			G or H	15-15	1750	6500	86	23
225	225,000	182,250	C or D	9-9	1687	3000	100	56
			E or F	12-12	1750	5000	96	34
			G or H	15-15	1750	6500	96	26
250	250,000	202,500	E or F	12-12	1875	5500	100	34
			G or H	15-15	1875	6500	100	29
			I, J, or K	18-18	3000	9375	63	20
300	300,000	243,000	E or F	12-12	2250	5500	100	41
			G or H	15-15	2250	6500	100	35
			I, J, or K	18-18	3000	11250	75	20
350	350,000	283,500	E or F	12-12	2625	5500	100	48
			G or H	15-15	2625	6500	100	40
			I, J, or K	18-18	4000	12000	66	22
400	400,000	324,000	E or F	12-12	3000	5500	100	55
			G or H	15-15	3000	6500	100	46
			I, J, or K	18-18	4000	12000	75	25
500	500,000	405,000	G or H	15-15	3125	6500	120	58
			I, J, or K	18-18	4000	9375	94	40
			L	20-18	4000	9375	94	40
600	600,000	486,000	G or H	15-15	3750	6500	120	69
			I, J, or K	18-18	4000	11250	113	40
			L	20-18	5000	11250	90	40
700	700,000	567,000	G or H	15-15	4375	6500	120	81
			I, J, or K	18-18	4375	13000	120	40
			L	20-18	4375	13000	120	40
800	800,000	648,000	G or H	15-15	5000	6500	120	92
			I, J, or K	18-18	5000	13000	120	46
			L	20-18	5000	14500	120	41
840	1,050,000	850,500	I, J, or K	18-18	6562	13000	120	61
			L	20-18	6562	13000	120	61
960	1,200,000	972,000	I, J, or K	18-18	7500	13000	120	69
			L	20-18	7500	14500	120	62

① Ratings are shown for elevations up to 2,000 feet. For higher elevations, refer to section "Considerations for Elevation" on page 10.

② For Variable Air Movement Applications, see page 21.

GENERAL PERFORMANCE DATA

Table 33.1 - Air Temperature Rise ① ② ③

Model Size	Btu/Hr Input ①	Btu/Hr Output ①	Air Temperature Rise Through Unit (°F)									
			20	40	50	60	70	80	90	100	110	120
75	75,000	60,750	2,813	1,406	1,125	938	804	703	625	562	-	-
100	100,000	81,000	3,750	1,875	1,500	1,250	1,071	938	833	750	-	-
125	125,000	101,250	4,688	2,344	1,875	1,563	1,339	1,172	1,042	937	-	-
150	150,000	121,500	5,500	2,813	2,250	1,875	1,607	1,406	1,250	1,125	-	-
175	175,000	141,750	5,500	3,281	2,625	2,188	1,875	1,641	1,458	1,312	-	-
200	200,000	162,000	6,500	3,750	3,000	2,500	2,143	1,875	1,667	1,500	-	-
225	225,000	182,250	6,500	4,219	3,375	2,813	2,411	2,109	1,875	1,687	-	-
250	250,000	202,500	9,375	4,688	3,750	3,125	2,679	2,344	2,083	1,875	-	-
300	300,000	243,000	11,250	5,625	4,500	3,750	3,214	2,813	2,500	2,250	-	-
350	350,000	283,500	12,000	6,563	5,250	4,375	3,750	3,281	2,917	2,625	-	-
400	400,000	324,000	12,000	7,500	6,000	5,000	4,286	3,750	3,333	3,000	-	-
500	500,000	405,000	-	9,375	7,500	6,250	5,357	4,688	4,167	3,750	3,409	3,125
600	600,000	486,000	-	11,250	9,000	7,500	6,429	5,625	5,000	4,500	4,091	3,750
700	700,000	567,000	-	13,000	10,500	8,750	7,500	6,563	5,833	5,250	4,773	4,375
800	800,000	648,000	-	14,500	12,000	10,000	8,571	7,500	6,667	6,000	5,455	5,000
840	1,050,000	850,500	-	-	-	13,000	11,250	9,844	8,750	7,875	7,159	6,562
960	1,200,000	972,000	-	-	-	14,500	12,857	11,250	10,000	9,000	8,182	7,500

① Ratings are shown for elevations up to 2000 feet. For higher elevations, refer to section "Considerations for Elevation" on page 10.

② Minimum Air Temperature Rise, Maximum Air Temperature Rise, and Maximum Discharge Air Temperature are as follows:

-For Model Sizes 75-400, Min Air Temp Rise is 20°F, Max Air Temp Rise is 100°F, and Max Discharge Air Temp is 150°F.

-For Model Sizes 500-800, Min Air Temp Rise is 40°F, Max Air Temp Rise is 120°F, and Max Discharge Air Temp is 150°F.

-For Model Sizes 840-960, Min Air Temp Rise is 60°F, Max Air Temp Rise is 120°F, and Max Discharge Air Temp is 150°F.

-Note that these are typical limits but may vary by Model Size. Refer to Table 32.1 for actual limits.

③ For Variable Air Movement Applications, see page 21.

Air Temperature Limits

The maximum allowable discharge air temperature is 150°F. The maximum allowable air temperature rise per furnace for Low Air Temperature Rise Units is 60°F. All system units are designed for a maximum allowable total static pressure of 3.0" W.C.

OPTION & ACCESSORY PRESSURE DROP DATA

Table 34.1 - Option & Accessory Pressure Drop Tables (in "W.C.) ①

Unit Size	Digit 16	CFM	Filters			Evap Cooler, 12" Media		Other		
			2" Permanent	2" Farr Aeroplate	2" Farr 30/30	Without Pre-Filters	With Pre-Filters	Downturn Plenum	Rainhood and Birdscreen	Discharge Damper
75	A, B, C, D	556	0.01	0.02	0.03	0.02	0.07	0.00	0.01	0.00
		600	0.01	0.02	0.03	0.02	0.07	0.00	0.01	0.01
		700	0.01	0.03	0.04	0.03	0.09	0.01	0.01	0.01
		800	0.01	0.03	0.04	0.04	0.12	0.01	0.02	0.01
		1,000	0.02	0.04	0.05	0.06	0.17	0.01	0.03	0.01
		1,200	0.02	0.05	0.06	0.08	0.22	0.02	0.03	0.01
		1,400	0.03	0.06	0.07	0.11	0.29	0.03	0.04	0.02
		1,600	0.04	0.07	0.09	0.15	0.36	0.04	0.06	0.02
		1,800	0.04	0.08	0.10	0.19	0.44	0.05	0.07	0.03
		2,000	0.05	0.10	0.11	0.23	0.53	0.06	0.08	0.03
		2,300	0.07	0.11	0.13	0.31	0.68	0.08	0.11	0.04
		2,778	0.09	0.15	0.16	0.45	0.96	0.12	0.15	0.06
100/125	C, D, E, F	741	0.02	0.02	0.02	0.02	0.08	0.00	0.03	0.01
		1,000	0.02	0.03	0.04	0.04	0.12	0.01	0.05	0.01
		1,500	0.04	0.05	0.07	0.08	0.23	0.02	0.07	0.02
		2,000	0.06	0.07	0.10	0.15	0.36	0.04	0.10	0.03
		2,500	0.08	0.10	0.14	0.23	0.53	0.07	0.13	0.04
		3,000	0.11	0.13	0.19	0.34	0.73	0.11	0.16	0.05
		3,500	0.13	0.16	0.24	0.46	0.97	0.15	0.19	0.07
		4,000	0.16	0.20	0.30	0.60	1.23	0.19	0.22	0.09
		4,500	0.20	0.25	0.37	4000 Max CFM for Evap		0.25	0.25	0.11
		4,630	0.21	0.26	0.39			0.26	0.26	0.11
150/175	C, D, E, F	1,111	0.02	0.03	0.04	0.03	0.09	0.02	0.02	0.01
		1,500	0.03	0.04	0.05	0.05	0.15	0.02	0.03	0.01
		2,000	0.04	0.06	0.08	0.09	0.24	0.04	0.05	0.02
		2,500	0.06	0.09	0.11	0.14	0.34	0.05	0.08	0.02
		3,000	0.08	0.11	0.15	0.20	0.46	0.07	0.10	0.04
		3,500	0.11	0.14	0.18	0.27	0.61	0.10	0.14	0.05
		4,000	0.13	0.18	0.23	0.35	0.77	0.13	0.18	0.06
		4,500	0.16	0.21	0.27	0.45	0.95	0.17	0.22	0.08
		5,000	0.19	0.25	0.32	0.55	1.15	0.21	0.27	0.10
		5,200	0.21	0.27	0.34	0.60	1.23	0.23	0.29	0.11
200/225	C, D, E, F, G, H	5,556	0.23	0.30	0.38	5200 Max CFM		0.26	0.33	0.13
		1,481	0.02	0.03	0.03	0.04	0.12	0.02	0.03	0.01
		2,000	0.02	0.04	0.04	0.07	0.19	0.03	0.05	0.01
		2,500	0.04	0.05	0.06	0.10	0.27	0.04	0.08	0.02
		3,000	0.05	0.07	0.08	0.15	0.36	0.06	0.10	0.04
		3,500	0.06	0.09	0.10	0.20	0.47	0.09	0.14	0.05
		4,000	0.08	0.11	0.12	0.27	0.60	0.11	0.18	0.06
		4,500	0.10	0.13	0.15	0.34	0.73	0.14	0.22	0.08
		5,000	0.11	0.16	0.18	0.42	0.89	0.18	0.27	0.10
		5,500	0.14	0.19	0.21	0.50	1.05	0.21	0.32	0.12
250/300 500/600	E, F, G, H	6,000	0.16	0.22	0.25	0.60	1.23	0.26	0.38	0.14
		6,500	0.18	0.25	0.28	6000 Max CFM		0.30	0.45	0.16
		1,852	0.02	0.05	0.05	0.05	0.15	0.02	0.07	0.02
		2,000	0.03	0.05	0.06	0.06	0.17	0.02	0.08	0.02
		2,500	0.04	0.07	0.09	0.09	0.24	0.03	0.09	0.03
		3,000	0.06	0.10	0.11	0.13	0.32	0.04	0.12	0.04
		3,500	0.08	0.12	0.15	0.17	0.41	0.06	0.14	0.06
		4,000	0.10	0.15	0.18	0.23	0.52	0.08	0.16	0.07
		4,500	0.13	0.18	0.22	0.29	0.64	0.10	0.19	0.09
		5,500	0.19	0.25	0.31	0.43	0.91	0.15	0.25	0.13
350/400 700/800 840/960	E, F, G, H	6,500	0.26	0.34	0.42	0.60	1.23	0.21	0.31	0.18
		7,250	0.32	0.41	0.51	6500 Max CFM		0.27	0.37	0.23
		1,925	0.01	0.03	0.03	0.02	0.08	0.02	0.07	0.02
		3,000	0.03	0.05	0.05	0.05	0.15	0.04	0.12	0.04
		4,000	0.05	0.08	0.09	0.09	0.23	0.08	0.16	0.07
		5,000	0.08	0.11	0.12	0.14	0.34	0.12	0.22	0.11
		6,000	0.11	0.15	0.16	0.20	0.46	0.18	0.28	0.16
		7,000	0.15	0.19	0.21	0.27	0.61	0.25	0.35	0.21
		8,000	0.20	0.24	0.27	0.35	0.77	0.33	0.42	0.28
		9,000	0.25	0.30	0.33	0.45	0.95	0.42	0.51	0.35
350/400 700/800 840/960	I, J, K	10,400	0.33	0.38	0.42	0.60	1.23	0.57	0.64	0.47
		11,111	0.38	0.43	0.47	10400 Max CFM		0.66	0.71	0.53
		2,593	0.02	0.04	0.04	0.05	0.16	0.02	0.03	0.01
		3,000	0.02	0.05	0.05	0.07	0.20	0.03	0.04	0.01
		3,500	0.03	0.06	0.06	0.10	0.25	0.04	0.05	0.01
		4,000	0.04	0.07	0.08	0.13	0.32	0.05	0.07	0.01
		4,500	0.05	0.09	0.10	0.16	0.39	0.06	0.09	0.02
		5,000	0.06	0.10	0.12	0.20	0.47	0.07	0.11	0.02
		5,500	0.07	0.12	0.14	0.24	0.55	0.09	0.14	0.03
		6,000	0.08	0.14	0.17	0.29	0.64	0.10	0.17	0.04
350/400 700/800 840/960	I, J, K	6,500	0.10	0.16	0.19	0.34	0.74	0.12	0.20	0.04
		7,000	0.11	0.18	0.22	0.39	0.85	0.14	0.23	0.05
		2,593	0.01	0.02	0.02	0.03	0.11	0.02	0.03	0.01
		3,000	0.02	0.02	0.03	0.04	0.14	0.03	0.04	0.01
		4,000	0.03	0.04	0.04	0.08	0.22	0.05	0.07	0.01
		5,000	0.04	0.05	0.06	0.12	0.31	0.07	0.11	0.02
		6,000	0.05	0.07	0.08	0.18	0.42	0.10	0.17	0.04
		7,000	0.07	0.10	0.11	0.24	0.55	0.14	0.23	0.05
		8,000	0.09	0.12	0.13	0.32	0.70	0.19	0.30	0.08
		9,000	0.12	0.15	0.16	0.40	0.86	0.24	0.38	0.10
350/400 700/800 840/960	I, J, K	10,000	0.14	0.18	0.19	0.50	1.04	0.30	0.48	0.14
		11,050	0.17	0.22	0.23	0.61	1.24	0.36	0.58	0.17
		12,000	0.20	0.26	0.27	11050 Max CFM		0.43	0.69	0.21
		12,500	0.22	0.28	0.29			0.47	0.75	0.23
		13,000	0.24	0.30	0.31			0.51	0.81	0.26

① Accessory / Option static pressure losses are approximate. Please consult the Accuspec selection software for static pressure losses at other than listed CFM.

BLOWER PERFORMANCE DATA

Table 35.1 - Unit Performance Tables ①②

Unit Size	Digit 16	Air Temp. Rise	CFM	Total Static Pressure, "W.C.																	
				0.25		0.50		0.75		1.00		1.25		1.50		2.00		2.50		3.00	
				BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM
75	A,B	100°F / -	556	0.09	679	0.15	871	0.22	1031	0.29	1170	0.37	1296	0.45	1411	0.63	1617	0.81	1800	1.01	1968
		79°F / -	700	0.14	747	0.21	924	0.29	1074	0.37	1206	0.46	1327	0.55	1438	0.75	1638	0.95	1818	1.17	1982
		69°F / -	800	0.18	801	0.26	966	0.35	1109	0.44	1237	0.54	1354	0.64	1462	0.84	1658	1.06	1832	1.30	1996
		56°F / -	1000	0.29	917	0.39	1062	0.50	1192	0.60	1310	0.72	1419	0.83	1522	1.07	1709	1.32	1879	-	-
		46°F / -	1200	0.45	1042	0.57	1171	0.69	1289	0.82	1397	0.94	1499	1.08	1595	1.35	1773	-	-	-	-
		40°F / -	1400	0.66	1173	0.80	1288	0.94	1395	1.08	1495	1.23	1589	1.38	1680	-	-	-	-	-	-
		35°F / -	1600	0.93	1308	1.09	1412	1.25	1509	1.42	1601	-	-	-	-	-	-	-	-	-	-
		31°F / -	1800	1.28	1445	1.46	1539	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		69°F / -	800	-	-	0.15	795	0.21	960	-	-	-	-	-	-	-	-	-	-	-	-
75	C,D	56°F / -	1000	-	-	0.20	822	0.28	975	0.36	1112	-	-	-	-	-	-	-	-	-	-
		46°F / -	1200	0.19	705	0.27	862	0.35	1003	0.44	1131	0.54	1250	0.65	1361	-	-	-	-	-	-
		40°F / -	1400	0.27	770	0.36	912	0.45	1041	0.55	1161	0.66	1273	0.77	1377	1.00	1572	-	-	-	-
		35°F / -	1600	0.37	839	0.47	968	0.57	1087	0.68	1199	0.80	1304	0.92	1403	1.17	1589	1.44	1760	1.72	1920
		31°F / -	1800	0.49	912	0.60	1030	0.72	1139	0.84	1244	0.96	1343	1.09	1437	1.36	1613	1.65	1777	1.94	1931
		28°F / -	2000	0.65	987	0.77	1095	0.90	1197	1.03	1295	1.16	1388	1.30	1477	1.59	1645	1.89	1802	2.20	1950
		24°F / -	2300	0.94	1104	1.08	1200	1.22	1292	1.37	1380	1.52	1465	1.67	1547	1.98	1703	2.31	1850	2.65	1990
		20°F / -	2778	1.59	1296	1.75	1377	1.92	1456	2.09	1532	2.26	1606	2.44	1679	2.80	1818	-	-	-	-
		100°F / -	741	-	-	0.15	808	0.23	962	0.30	1093	0.38	1212	0.47	1320	0.60	1514	0.86	1686	1.07	1840
100/125 Start 125	C,D	80°F/100°F	926	0.13	670	0.21	846	0.29	993	0.38	1121	0.47	1236	0.56	1342	0.77	1532	0.99	1702	1.22	1856
		62°F/77°F	1200	0.22	758	0.31	916	0.41	1052	0.52	1173	0.62	1282	0.74	1384	0.97	1568	1.22	1733	1.48	1884
		53°F/66°F	1400	0.30	828	0.41	975	0.53	1103	0.64	1218	0.76	1323	0.89	1422	1.15	1600	1.42	1762	1.70	1910
		41°F/51°F	1800	0.55	982	0.69	1108	0.83	1220	0.98	1325	1.12	1422	1.27	1513	1.58	1681	1.90	1834	2.23	1976
		34°F/42°F	2200	0.93	1145	1.10	1254	1.27	1354	1.44	1449	1.61	1537	1.79	1621	2.15	1778	2.52	1923	2.90	2057
		28°F/36°F	2600	1.45	1315	1.65	1410	1.85	1500	2.05	1585	2.25	1666	2.46	1744	1.35	1638	-	-	-	-
		25°F/31°F	3000	2.16	1489	2.39	1573	2.61	1654	2.84	1731	-	-	-	-	-	-	-	-	-	-
		41°F/51°F	1800	0.28	497	0.41	622	0.56	735	0.72	837	-	-	-	-	-	-	-	-	-	-
		34°F/42°F	2200	0.43	553	0.58	662	0.75	762	0.93	855	1.12	942	1.33	1025	-	-	-	-	-	-
End 100	C,D	28°F/36°F	2600	0.63	614	0.81	710	1.00	800	1.20	885	1.41	965	1.63	1042	-	-	-	-	-	-
		25°F/31°F	3000	0.91	680	1.11	766	1.32	847	1.54	1731	1.77	997	2.01	1068	2.51	1202	3.04	1328	3.60	1446
		22°F/27°F	3400	1.26	748	1.48	825	1.72	899	1.96	970	2.21	1038	2.47	1104	3.01	1229	3.58	1347	4.17	1459
		20°F/25°F	3704	1.58	802	1.83	873	2.08	942	2.34	1008	2.60	1072	2.88	1135	3.45	1254	4.04	1367	4.67	1474
		- /23°F	4100	2.09	873	2.35	938	2.63	1001	2.91	1062	3.20	1122	3.49	1180	4.10	1291	4.74	1398	-	-
		- /20°F	4630	2.93	969	3.23	1028	3.53	1085	3.84	1140	4.16	1194	4.48	1247	-	-	-	-	-	-
		100°F/117°F	1111	0.19	727	0.28	884	0.38	1023	0.48	1148	0.59	1262	0.70	1369	0.94	1563	1.21	1738	1.48	1899
		86°F/100°F	1296	0.27	793	0.37	937	0.47	1066	0.59	1184	0.71	1293	0.83	1395	1.09	1582	1.37	1752	1.66	1909
		79°F/93°F	1400	0.32	832	0.42	970	0.54	1093	0.66	1208	0.78	1313	0.91	1412	1.18	1596	1.47	1763	1.78	1917
150/175 Start 175	C,D	62°F/72°F	1800	0.59	994	0.72	1109	0.86	1216	1.00	1316	1.15	1410	1.30	1500	1.62	1667	1.95	1823	2.29	1967
		51°F/59°F	2200	1.00	1166	1.16	1264	1.32	1356	1.49	1444	1.66	1529	1.84	1610	2.20	1762	2.57	1906	2.96	2041
		43°F/50°F	2600	1.58	1344	1.76	1429	1.95	1510	2.14	1589	2.34	1664	2.54	1737	2.95	1877	-	-	-	-
		37°F/43°F	3000	2.35	1526	2.57	1600	2.78	1673	3.00	1743	-	-	-	-	-	-	-	-	-	-
		86°F/100°F	1296	-	-	0.25	609	0.37	734	-	-	-	-	-	-	-	-	-	-	-	-
		79°F/93°F	1400	0.17	474	0.28	615	0.40	737	-	-	-	-	-	-	-	-	-	-	-	-
		62°F/72°F	1800	0.28	526	0.41	650	0.55	760	0.70	859	0.85	952	-	-	-	-	-	-	-	-
		51°F/59°F	2200	0.44	588	0.59	697	0.75	796	0.91	887	1.09	972	1.27	1052	1.67	1201	-	-	-	-
		43°F/50°F	2600	0.67	657	0.83	753	1.01	842	1.19	925	1.39	1004	1.59	1078	2.02	1218	2.47	1348	2.96	1469
150/175	E,F	37°F/43°F	3000	0.96	729	1.15	815	1.35	895	1.55	972	1.76	1044	1.98	1114	2.45	1245	2.94	1368	3.45	1483
		33°F/38°F	3400	1.35	804	1.55	881	1.77	955	2.00	1025	2.23	1092	2.47	1157	2.96	1280	3.49	1396	4.03	1505
		29°F/34°F	3800	1.82	880	2.05	951	2.29	1018	2.53	1083	2.79	1146	3.04	1206	3.58	1322	4.14	1431	4.72	1535
		26°F/31°F	4200	2.40	959	2.66	1023	2.92	1085	3.18	1145	3.45	1204	3.73	1260	4.30	1369	4.90	1472	-	-
		24°F/28°F	4700	3.30	1058	3.58	1116	3.87	1172	4.16	1227	4.46	1281	4.76	1333	-	-	-	-	-	-
		21°F/25°F	5200	4.40	1158	4.71	1212	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		200°F/113°F	1481	0.36	871	0.48	1016	0.60	1144	0.73	1259	0.85	1366	0.99	1465	1.26	1646	1.54	1808	1.84	1958
		89°F/100°F	1667	0.48	943	0.61	1078	0.75	1198	0.88	1309	1.03	1411	1.17	1507	1.47	1682	1.77	1842	2.09	1988
		85°F/95°F	1750	0.54	975	0.68	1106	0.82	1224	0.96	1332	1.11	1433	1.26	1527	1.57	1700	1.88	1857	2.21	2003
200/225 Start 225	C,D	74°F/83°F	2000	0.76	1077	0.92	1197	1.08	1306	1.24	1407	1.40	1502	1.57	1592	1.91	1758	2.26	1910	2.62	2051
		66°F/74°F	2250	1.04	1181	1.21	1291	1.39	1393	1.57	1488	1.75	1577	1.94	1663	2.31	1822	2.69	1969	-	-
		59°F/67°F	2500	1.38	1288	1.57	1389	1.77	1484	1.97	1573	2.17	1658	2.37	1739	2.78	1892	-	-	-	-
		54°F/61°F	2750	1.79	1396	2.00	1490	2.22	1579	2.44	1663	2.66	1743	2.88	1820	-	-	-	-	-	-
		49°F/56°F	3000	2.28	1506	2.51	1593	2.75	1677	2.98	1756	-	-	-	-	-	-	-	-	-	-
		85°F/95°F	1750	0.29	594	0.43	723	0.58	838	0.75	944	0.94	1042	1.14	1134	1.58	1303	2.07	1458	2.60	1600
		74°F/83°F	2000	0.40	642	0.54	759	0.71	866	0.88	966	1.08	1058	1.28	1146	1.74	1309	2.23	1458	2.78	1595
		59°F/67°F	2500	0.68	746	0.85	845	1.04	938	1.23	1025	1.45	1108	1.67	1188	2.15	1337	2.67	1475	3.24	1604
		49°F/56°F	3000	1.09	857	1.29	942	1.50	1024	1.72	1101	1.95	1176	2.1							

Table 36.1 - Unit Performance Tables ①②

① Total static pressure should include external static pressure and accessory / option static pressure from Table 34.1. Unit internal resistance has been included in the unit performance tables.

② Brake Horsepower and RPM values are approximate values only. Please consult the AccuSpec selection software for values at other than listed CFM / static pressures

BLOWER PERFORMANCE DATA

Table 37.1 - Unit Performance Tables ①②

Unit Size	Digit 16	Air Temp Rise	CFM	Total Static Pressure Inches "W.C."																	
				0.25		0.50		0.75		1.00		1.25		1.50		2.00		2.50		3.00	
				BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM	BHP	RPM
500/600 Start 600	G or H →	120°F / -	3086	0.62	529	0.82	620	1.03	703	1.26	779	1.50	849	1.75	916	2.28	1038	2.84	1149	3.44	1252
		106°F / -	3500	0.84	575	1.06	658	1.30	736	1.54	807	1.80	874	2.07	937	2.63	1054	3.23	1162	3.86	1262
		100°F / 120°F	3704	0.97	598	1.20	678	1.45	753	1.70	822	1.97	887	2.25	949	2.83	1064	3.44	1170	4.09	1268
		93°F / 111°F	4000	1.18	633	1.43	709	1.69	779	1.96	846	2.24	908	2.53	968	3.14	1080	3.78	1183	4.45	1279
		82°F / 99°F	4500	1.61	693	1.88	762	2.17	827	2.46	889	2.77	948	3.09	1001	3.74	1110	4.43	1208	-	-
		74°F / 89°F	5000	2.13	755	2.43	818	2.75	878	3.07	936	3.40	991	3.74	1044	4.44	1145	-	-	-	-
		67°F / 81°F	5500	2.77	818	3.10	876	3.44	932	3.79	986	4.15	1038	4.51	1088	-	-	-	-	-	-
		62°F / 74°F	6000	3.53	882	3.89	936	4.25	988	4.63	1038	-	-	-	-	-	-	-	-	-	-
500/600 Start 600	I, J, K →	57°F / 68°F	6500	4.41	946	4.80	996	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		120°F / -	3086	0.46	401	0.69	496	0.95	580	1.23	657	-	-	-	-	-	-	-	-	-	-
		100°F / 120°F	3704	0.69	443	0.95	527	1.23	604	1.54	675	-	-	-	-	-	-	-	-	-	-
		93°F / 111°F	4000	0.82	464	1.09	544	1.39	618	1.71	686	2.05	749	2.42	810	-	-	-	-	-	-
		74°F / 89°F	5000	1.43	542	1.75	609	2.09	673	2.46	733	2.84	790	3.24	844	4.09	946	5.01	1041	-	-
		62°F / 74°F	6000	2.31	624	2.68	682	3.07	738	3.48	791	3.91	842	4.35	891	5.29	984	6.28	1072	7.33	1155
		53°F / 63°F	7000	3.51	709	3.94	760	4.38	809	4.84	857	5.31	903	5.80	947	6.82	1032	7.90	1113	9.03	1191
		46°F / 56°F	8000	5.09	797	5.57	842	6.07	886	6.58	928	7.10	970	7.64	1010	8.75	1089	9.92	1163	11.13	1235
End 500	→	41°F / 49°F	9000	7.11	885	7.65	926	8.20	965	8.76	1001	9.33	1042	9.92	1079	11.13	1151	12.38	1220	13.69	1287
		- / 44°F	10000	9.62	975	10.21	1012	10.81	1048	11.43	1083	12.05	1118	12.69	1152	14.00	1218	15.35	1283	-	-
		- / 43°F	10400	10.77	1011	11.38	1046	12.01	1081	12.64	1115	13.29	1149	13.95	1182	15.30	1247	-	-	-	-
		- / 40°F	11000	12.66	1065	13.31	1099	13.97	1132	14.64	1164	15.32	1197	16.01	1228	17.42	1290	-	-	-	-
		- / 40°F	11111	13.04	1075	13.69	1109	14.36	1141	15.03	1174	15.72	1205	16.41	1237	17.83	1298	-	-	-	-
		62°F / 74°F	6000	1.69	512	1.97	565	2.26	615	2.57	664	2.89	710	3.23	755	-	-	-	-	-	-
		53°F / 63°F	7000	2.57	580	2.89	626	3.22	671	3.56	714	3.92	756	4.29	797	5.06	874	-	-	-	-
		46°F / 56°F	8000	3.73	650	4.09	691	4.46	731	4.84	770	5.23	808	5.64	845	6.47	916	7.35	984	-	-
700/800	G or H →	41°F / 49°F	9000	5.21	721	5.60	758	6.01	795	6.43	830	6.86	864	7.30	898	8.21	964	9.16	1027	10.14	1088
		- / 44°F	10000	7.04	793	7.48	827	7.93	860	8.39	892	8.85	924	9.33	955	10.31	1016	11.33	1074	12.38	1131
		- / 43°F	10400	7.88	823	8.34	855	8.80	887	9.28	918	9.76	949	10.25	979	11.26	1038	12.31	1095	13.38	1150
		- / 40°F	11000	9.27	866	9.75	897	10.24	927	10.74	957	11.24	986	11.76	1015	12.81	1071	13.90	1126	-	-
		- / 40°F	11111	9.54	874	10.03	905	10.52	935	11.02	964	11.53	993	12.05	1022	13.12	1078	14.21	1132	-	-
		120°F / -	4321	1.51	685	1.80	760	2.11	830	2.43	896	2.77	958	3.13	1018	3.88	1131	4.69	1236	-	-
		115°F / -	4500	1.68	708	1.98	780	2.30	847	2.63	912	2.98	973	3.34	1032	4.11	1142	4.94	1245	-	-
		Start 800	→	105°F / 120°F	4938	2.15	763	2.48	89	2.82	893	3.17	953	3.54	1011	3.93	1066	4.74	1172	-	-
104°F / 119°F	5000			2.23	770	2.55	836	2.90	899	3.26	959	3.63	1016	4.02	1072	4.83	1176	-	-	-	-
94°F / 108°F	5500			2.89	834	3.25	895	3.62	953	4.00	1009	4.40	1063	4.81	1116	-	-	-	-	-	-
86°F / 99°F	6000			3.68	900	4.06	956	4.46	1010	4.87	1062	-	-	-	-	-	-	-	-	-	-
80°F / 91°F	6500			4.61	965	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
120°F / -	4321			0.87	443	1.14	421	1.42	591	1.72	657	2.04	717	2.37	774	3.08	879	3.84	974	4.65	1063
104°F / 119°F	5000			1.26	488	1.55	558	1.87	623	2.20	683	2.54	740	2.90	794	3.66	894	4.47	985	5.33	1071
86°F / 99°F	6000			2.02	558	2.36	619	2.73	677	3.10	731	3.49	782	3.89	832	4.73	924	5.62	1010	6.55	1091
700/800	I, J, K →	65°F / 74°F	8000	4.44	707	4.89	755	5.35	801	5.82	845	6.30	888	6.79	930	7.81	1009	8.87	1085	9.96	1156
		58°F / 66°F	9000	6.19	784	6.69	827	7.20	869	7.72	909	8.25	949	8.79	987	9.90	1061	11.04	1131	12.23	1199
		52°F / 59°F	10000	8.36	861	8.91	901	9.47	939	10.04	976	10.62	1012	11.21	1048	12.42	1117	13.66	1183	14.93	1246
		47°F / 54°F	11000	11.00	940	11.60	976	12.22	1011	12.84	1045	13.47	1079	14.11	1112	15.41	1176	16.74	1238	-	-
		43°F / 49°F	12000	14.16	1019	14.81	1052	15.48	1085	16.15	1117	16.83	1148	17.52	1179	18.92	1239	-	-	-	-
		40°F / 46°F	13000	17.88	1098	18.59	1129	19.30	1159	-	-	-	-	-	-	-	-	-	-	-	-
		65°F / 74°F	8000	3.26	566	3.60	611	3.95	654	4.31	696	4.67	736	5.05	774	5.84	848	6.66	918	7.51	984
		58°F / 66°F	9000	4.54	626	4.92	667	5.30	706	5.70	744	6.10	780	6.52	816	7.37	885	8.25	950	9.17	1012
End 700	→	52°F / 59°F	10000	6.13	687	6.54	724	6.97	760	7.40	794	7.85	828	8.30	861	9.22	925	10.17	987	11.15	1046
		47°F / 54°F	11000	8.06	749	8.52	782	8.98	815	9.45	847	9.93	879	10.42	910	11.41	969	12.43	1027	13.48	1083
		47°F / 54°F	11050	8.17	752	8.62	785	9.09	818	9.56	850	10.04	881	10.53	912	11.53	972	12.56	1029	13.61	1084
		43°F / 49°F	12000	10.37	811	10.86	842	11.37	872	11.88	902	12.40	931	12.92	960	13.99	1016	15.08	1070	16.20	1123
		40°F / 46°F	13000	13.09	873	13.63	902	14.17	930	14.72	958	15.27	986	15.83	1013	16.98	1065	18.14	1116	19.33	1166
		- / 42°F	14000	16.26	936	16.83	963	17.41	989	18.00	1015	18.59	1041	19.19	1066	-	-	-	-	-	-
		- / 41°F	14500	18.02	968	18.61	994	19.21	1019	19.82	1045	-	-	-	-	-	-	-	-	-	-
		840/960	I, J, K →	120°F / -	6481	2.72	630	3.09	685	3.48	736	3.88	785	4.30	832	4.72	876	5.60	960	6.52	1038
111°F / -	7000			3.36	672	3.76	723	4.17	772	4.60	818	5.04	863	5.49	905	6.42	986	7.38	1061	8.39	1133
105°F / 120°F	7407			3.93	705	4.35	754	4.79	800	5.23	845	5.69	888	6.16	929	7.13	1007	8.13	1081	9.17	1151
97°F / 111°F	8000			4.87	754	5.33	799	5.90	843	6.27	885	6.76	926	7.26	965	8.28	1040	9.33	1111	10.43	1179
86°F / 99°F	9000			6.80	837	7.31	878	7.83	918	8.36	956	8.90	994	9.44	1030	10.56	1100	11.71	1166	12.90	1230
78°F / 89°F	10000			9.20	921	9.76	958	10.33	995	10.91	1030	11.50	1065	12.10	1099	13.32	1164	14.56	1226	-	-
70°F / 80°F	11050			12.28	1010	12.89	1044	13.52	1078	14.16	1110	14.80	1142	15.45	1173	16.77	1234	-	-	-	-
65°F / 74°F	12000			15.60	1091	16.27	1123	16.95	1154	17.63	1184	18.32	1214	19.02	1243	-	-	-	-	-	-
End 840	L →	62°F / 71°F	12500	17.58	1134	18.27	1164	18.97	1194	19.6											

BLOWER SHEAVE ASSEMBLY DATA

Adjusting the Blower Drive Sheave Setting

All units include a sheave assembly indicated by Digit 19 of the model nomenclature. Within that assembly are the fixed blower sheave, adjustable motor sheave, and belt(s) to provide a method of adjusting the blower speed to balance the airflow based on actual external static pressure for the installation. The motor sheave is adjusted at the factory for external static conditions indicated on the order detail, however actual external static often varies from design, resulting in a need to adjust the equipment to provide correct design airflow.

To determine how many turns open the motor sheave should be set for:

1. Locate the unit Model Identification Plate and identify the following model number digits:
 - a. Digits 4-6 = Model Size
 - b. Digit 16 = Blower Size
 - c. Digit 19 = Sheave Arrangement
2. Use Table 34.1 to determine the individual static pressure drops for any features included on the unit for the design airflow. Add those and the design external static pressure to calculate the total static pressure.
3. Use Tables 35.1 through 37.1 to determine the blower speed (RPM) required to meet the job requirements.
4. Use Table 39.1 to determine the RPM range and approximately blower speeds for each 1/2 turn open of the adjustable motor sheave. Find the RPM that is closest to one value shown to determine the turns open and set the motor sheave as described in the section "Blower Adjustments" on page 19.


Example:

Determine motor sheave turns open for a unit operating at 4000 CFM with a design external static pressure (ESP) of 0.60"W.C. as follows:

1. From the Model Nomenclature:
 - a. Model size (Model Digit 4-6) = 400
 - b. Blower size (Model Digit 16) = E
 - c. Sheave arrangement (Model Digit 19) = J
2. From Table 34.1, the unit includes 2" Farr 30/30 Filters (0.08"W.C. static) and Rainhood & Birdscreen (0.07"W.C. static). Total static pressure is $0.08+0.07+0.60=0.75$ "W.C.
3. From Table 36.1, the blower speed is 1078 RPM.
4. From Table 39.1, the blower range is 1029-1332 RPM. The closest value to 1078 RPM in the row of Blower RPM by Sheave Turns Open is 1090 RPM, which corresponds to 4.0 turns open.

If actual job ESP after installation was measured at 0.75"W.C., the process above would be repeated with the new TSP of 0.90"W.C.

Figure 38.1 - Blower Section



BLOWER SHEAVE ASSEMBLY DATA

Table 39.1 - Sheave Assembly Data

Blower Type Digit 16	Sheave Digit 19	RPM Range	Blower RPM by Sheave Turns Open Setting (Approx.)										
			0	0.5	1	1.5	2	2.5	3	3.5	4	4.5	5
A or B (9-7 Blower)	A, B	656-1001	1001	967	932	898	863	829	794	760	725	691	656
	C, D, E	978-1265	1265	1236	1208	1179	1150	1122	1093	1064	1035	1007	978
	F, G	1150-1561	1561	1520	1479	1438	1397	1356	1314	1273	1232	1191	1150
	H, I	1526-1858	1858	1825	1792	1758	1725	1692	1659	1626	1592	1559	1526
	J, K	1763-2147	2147	2109	2070	2032	1993	1955	1917	1878	1840	1801	1763
C or D (9-9 Blower)	A, B	656-1001	1001	967	932	898	863	829	794	760	725	691	656
	C, D, E	978-1265	1265	1236	1208	1179	1150	1122	1093	1064	1035	1007	978
	F, G, H	1150-1561	1561	1520	1479	1438	1397	1356	1314	1273	1232	1191	1150
	I, J, K	1526-1858	1858	1825	1792	1758	1725	1692	1659	1626	1592	1559	1526
	L, M, N	1763-2147	2147	2109	2070	2032	1993	1955	1917	1878	1840	1801	1763
E or F (12-12 Blower)	A, B	468-715	715	690	666	641	616	592	567	542	517	493	468
	C, D, E	644-874	874	851	828	805	782	759	736	713	690	667	644
	F, G, H	863-1078	1078	1057	1035	1014	992	971	949	928	906	885	863
	I, J, K, Q	1029-1332	1332	1302	1271	1241	1211	1181	1150	1120	1090	1059	1029
	L, M, N	1150-1438	1438	1409	1380	1352	1323	1294	1265	1236	1208	1179	1150
	O, P	1327-1659	1659	1626	1593	1559	1526	1493	1460	1427	1393	1360	1327
G or H (15-15 Blower)	A, B, C	410-625	625	604	582	561	539	518	496	475	453	432	410
	D, E, F	568-771	771	751	730	710	690	670	649	629	609	588	568
	G, H, I	767-958	958	939	920	901	882	863	843	824	805	786	767
	J, K, L, O	934-1136	1136	1116	1096	1075	1055	1035	1015	995	974	954	934
	M, N	1136-1380	1380	1356	1331	1307	1282	1258	1234	1209	1185	1160	1136
I or J (18-18 Blower with Under 15 HP Motor)	A, B, C	491-649	649	633	617	602	586	570	554	538	523	507	491
	D, E, F, G	586-744	744	728	712	697	681	665	649	633	618	602	586
	H, I, J	682-821	821	807	793	779	765	752	738	724	710	696	682
	K, L, M, N	821-1009	1009	990	971	953	934	915	896	877	859	840	821
	O, P, Q, R	995-1161	1161	1144	1128	1111	1095	1078	1061	1045	1028	1012	995
	S, T, U	1101-1285	1285	1267	1248	1230	1211	1193	1175	1156	1138	1119	1101
K (18-18 Blower with 15 HP Motor & Up)	A, B, G, H	826-1009	1009	991	972	954	936	918	899	881	863	844	826
	C, D, I, J	995-1161	1161	1144	1128	1111	1095	1078	1061	1045	1028	1012	995
	E, F, K, L	1101-1285	1285	1267	1248	1230	1211	1193	1175	1156	1138	1119	1101
	M, N	1232-1438	1438	1417	1397	1376	1356	1335	1314	1294	1273	1253	1232
L (20-18 Blower)	A, B	491-649	649	633	617	602	586	570	554	538	523	507	491
	C, D, E	626-765	765	751	737	723	709	696	682	668	654	640	626
	F, G, H, I, J, K	765-901	901	887	874	860	847	833	819	806	792	779	765
	L, M, N, O, P, Q	901-1059	1059	1043	1027	1012	996	980	964	948	933	917	901
	R, S, T, U, V	995-1161	1161	1144	1128	1111	1095	1078	1061	1045	1028	1012	995
	W, X, Y, Z	1101-1285	1285	1267	1248	1230	1211	1193	1175	1156	1138	1119	1101

DIMENSIONS - UNIT

Figure 40.1 - Outdoor STANDARD Blower Package Unit (Model Digit 2=B, Digit 16=A through H)




Figure 40.2 - Outdoor STANDARD Blower Downturn Package Unit (Model Digit 2=D, Digit 16=A through H)




Table 40.1 - Outdoor STANDARD Blower Unit (Model Digit 2=B or D, Digit 16=A through H)

Model Size	Blower Type (Digit 16)	Furnace Qty	Dimensions (inches)										Gas Conn.
			A	E	F	K	N	P	S	T	Y	Z	
75	All	1	33.75	18.98	15.18	20.02	39.23	32.06	84.41	108.39	81.49	110.82	1/2
100/125	All	1	33.75	18.98	17.69	20.02	39.23	34.56	84.41	108.39	81.49	110.82	1/2
150/175	All	1	33.75	18.98	21.94	23.99	39.23	38.82	84.41	108.39	81.49	110.82	1/2
200/225	All	1	37.75	22.98	24.06	23.99	43.23	40.94	84.41	108.39	81.49	110.82	1/2
250/300	E, F, G, or H	1	37.75	22.98	27.09	29.96	43.23	44.05	84.41	108.39	81.49	110.82	3/4
350/400	E, F, G, or H	1	37.75	22.98	38.60	41.90	43.23	55.57	84.41	108.39	81.49	110.82	3/4
500/600	G or H	2	37.75	22.98	27.09	29.96	43.23	44.05	117.53	146.77	114.94	144.12	3/4
700/800	G or H	2	37.75	22.98	38.60	41.90	43.23	55.57	117.53	146.77	114.94	144.12	3/4

- ① For Right Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
- ② For Left Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
- ③ For Right Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.
- ④ For Left Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.

DIMENSIONS - UNIT

Figure 42.1 - Outdoor STANDARD Blower Cooling Package Unit (Model Digit 2=C, Digit 16=A through H)




Figure 42.2 - Outdoor STANDARD Blower Cooling & Downturn Packaged Unit (Model Digit 2=P, Digit 16=A-H)




Table 42.1 - Outdoor STANDARD Blower Unit (Model Digit 2=C or P, Digit 16=A through H)

Model Size	Blower Type (Digit 16)	Dimensions (inches)							Gas Conn.
		A	G	H	J	K	N	P	
75	All	33.75	28.75	18.00	25.00	20.02	39.23	32.06	1/2
100/125	All	33.75	28.75	21.00	25.00	20.02	39.23	34.56	1/2
150/175	All	33.75	28.75	24.00	25.00	23.99	39.23	38.82	1/2
200/225	All	37.75	32.75	27.00	28.00	23.99	43.23	40.94	1/2
250/300	E, F, G, or H	37.75	32.75	30.00	28.00	29.96	43.23	44.05	3/4
350/400	E, F, G, or H	37.75	32.75	42.00	28.00	41.90	43.23	55.57	3/4

- ① For Right Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
 ② For Left Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
 ③ For Right Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.
 ④ For Left Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.

DIMENSIONS - UNIT

Figure 43.1 - Outdoor EXTENDED Blower Cooling Package Unit (Model Digit 2=C, Digit 16=I, J, K, or L)




Figure 43.2 - Outdoor EXTENDED Blower Cooling & Downturn Unit (Model Digit 2=C, Digit 16=I, J, K, or L)




Table 43.1 - Outdoor EXTENDED Blower Unit (Model Digit 2=C or P, Digit 16=I, J, K, or L)

Model Size	Blower Type (Digit 16)	Dimensions (inches)					Gas Conn.
		F	H	K	N	P	
250/300	I, J, or K	27.09	30.00	29.96	43.23	44.05	3/4
350/400	I, J, or K	38.60	42.00	41.90	43.23	55.57	3/4

- ① For Right Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
 ② For Left Hand Access Units - Location of drill locator dimples for field drilled gas connection entry holes - one side of unit and one on bottom.
 ③ For Right Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.
 ④ For Left Hand Access Units - Location of drill locator dimples for field drilled electrical connection, entry holes identical as side electrical connections.

DIMENSIONS - UNIT BASE

Figure 44.1 - Unit Base Dimensions




Table 44.1 - Outdoor Unit Base Rail Dimensions for Model Digit 2=B or D (All dimensions in inches)

Model Size	Blower Type (Digit 16)	Dimensions										
		Digit 2=B		Digit 2=D		Digit 2=B or D						
		A	C	A	C	B	E	F ①	G ①	H	J	M
75	All	84.41	81.49	113.63	110.82	34.85	19.52	78.66	53.72	1.53	32.00	6.23
100/125	All	84.41	81.49	113.63	110.82	37.36	19.52	78.66	53.72	1.53	34.50	7.49
150/175	All	84.41	81.49	113.63	110.82	41.61	23.49	78.66	53.72	1.53	38.75	7.63
200/225	All	84.41	81.49	113.63	110.82	43.71	23.49	78.66	53.72	1.53	40.85	8.69
250/300	E,F,G, or H	84.41	81.49	113.63	110.82	46.75	29.46	78.66	53.72	1.53	43.89	7.21
250/300	I, J, or K	120.00	117.34	149.22	146.66	46.75	29.46	114.23	84.29	1.28	43.89	7.21
350/400	E,F,G, or H	84.41	81.49	113.63	110.82	58.27	41.40	78.66	53.72	1.53	55.41	7.00
350/400	I, J, or K	120.00	117.34	149.22	146.66	58.27	41.40	114.23	82.29	1.28	55.41	7.00
500/600	G or H	117.53	114.94	146.77	144.12	46.75	29.46	78.66	53.72	1.53	43.89	7.21
500/600	I, J, K, or L	153.12	150.74	182.36	180.00	46.75	29.46	114.23	82.29	1.28	43.89	7.21
700/800	G or H	117.53	114.94	146.77	144.12	58.27	41.40	78.66	53.72	1.53	55.41	7.00
700/800	I, J, K, or L	153.12	150.74	182.36	180.00	58.27	41.40	114.23	82.29	1.28	55.41	7.00
840/960	I, J, K, or L	186.52	184.14	215.77	213.40	58.27	41.40	114.23	82.29	1.28	55.41	7.00

Table 44.2 - Outdoor Unit Base Rail Dimensions Model Digit 2=C or P (All dimensions in inches)

Model Size	Blower Type (Digit 16)	Dimensions										
		Digit 2=C		Digit 2=P		Digit 2=C or P						
		A	C	A	C	B	E	F	G	H	J	M
75	All	108.39	105.49	137.63	134.82	34.85	19.52	78.66	53.72	1.53	32.00	6.23
100/125	All	108.39	105.49	137.63	134.82	37.36	19.52	78.66	53.72	1.53	34.50	7.49
150/175	All	108.39	105.49	137.63	134.82	41.61	23.49	78.66	53.72	1.53	38.75	7.63
200/225	All	108.39	105.49	137.63	134.82	43.71	23.49	78.66	53.72	1.53	40.85	8.69
250/300	E,F,G, or H	108.39	105.49	137.63	134.82	46.75	29.46	78.66	53.72	1.53	43.89	7.21
250/300	I, J, or K	143.98	141.34	173.22	170.66	46.75	29.46	114.23	82.29	1.28	43.89	7.21
350/400	E,F,G, or H	108.39	105.49	137.63	134.82	58.27	41.40	78.66	53.72	1.53	55.41	7.00
350/400	I, J, or K	143.98	141.34	173.22	170.66	58.27	41.40	114.23	82.29	1.28	55.41	7.00

① Gas connection for 1st furnace. For Model sizes 500-800 add 33.5" for second furnace gas connection.
For Model sizes 840-960 add 33.50" and 67.00" for second and third furnace gas connections.

DIMENSIONS - ROOF CURBS

Figure 45.1 - Roof Curb Dimensions




Table 45.1 - Roof Curb Dimensions Model Digit 2=B or D (All dimensions in inches)

Model Size	Blower Type (Digit 16)	Dimensions												
		Digit 2=B				Digit 2=D				Digit 2=B or D				
		A	B	C	D	A	B	C	D	E	F	G	H	J ①
75	All	88.77	76.77	-	-	117.98	105.98	-	-	39.33	27.33	3.97	19.52	74.84
100/125	All	88.77	76.77	-	-	117.98	105.98	-	-	41.84	29.84	5.22	19.52	74.84
150/175	All	88.77	76.77	-	-	117.98	105.98	-	-	46.18	34.18	5.41	23.49	74.84
200/225	All	88.77	76.77	-	-	117.98	105.98	-	-	48.22	36.22	6.43	23.49	74.84
250/300	E,F,G, or H	88.77	76.77	-	-	117.98	105.98	-	-	51.25	39.25	4.96	29.46	74.84
250/300	I, J, or K	124.61	112.61	-	-	153.83	141.63	105.98	35.85	51.25	39.25	4.96	29.46	110.41
350/400	E,F,G, or H	88.77	76.77	-	-	117.98	105.98	-	-	62.76	50.76	4.74	41.40	74.84
350/400	I, J, or K	124.61	112.61	-	-	153.83	141.63	105.98	35.85	62.76	50.76	4.74	41.40	110.41
500/600	G or H	121.89	109.89	-	-	151.10	139.10	105.98	33.12	51.25	39.25	4.96	29.46	74.84
500/600	I, J, K, or L	157.74	145.74	105.98	39.76	186.98	174.98	105.98	69.00	51.25	39.25	4.96	29.46	110.41
700/800	G or H	121.89	109.89	-	-	151.10	139.10	105.98	33.12	62.76	50.76	4.74	41.40	74.84
700/800	I, J, K, or L	157.74	145.74	105.98	39.76	186.98	174.98	105.98	69.00	62.76	50.76	4.74	41.40	110.41
840/960	I, J, K, or L	191.14	179.14	105.98	73.16	220.39	208.39	105.98	102.41	62.76	50.76	4.74	41.40	110.41

Table 45.2 - Roof Curb Dimensions Model Digit 2=C or P (All dimensions in inches)

Model Size	Blower Type (Digit 16)	Dimensions												
		Digit 2=C				Digit 2=P				Digit 2=C or P				
		A	B	C	D	A	B	C	D	E	F	G	H	J
75	All	112.74	100.74	-	-	141.98	129.98	100.74	29.24	39.33	27.33	3.97	19.52	74.84
100/125	All	112.74	100.74	-	-	141.98	129.98	100.74	29.24	41.84	29.84	5.22	19.52	74.84
150/175	All	112.74	100.74	-	-	141.98	129.98	100.74	29.24	46.18	34.18	5.41	23.49	74.84
200/225	All	112.74	100.74	-	-	141.98	129.98	100.74	29.24	48.22	36.22	6.43	23.49	74.84
250/300	E,F,G, or H	112.74	100.74	-	-	141.98	129.98	100.74	29.24	51.25	39.25	4.96	29.46	74.84
250/300	I, J, or K	148.59	136.59	105.98	30.61	177.83	165.83	105.98	59.85	51.25	39.25	4.96	29.46	110.41
350/400	E,F,G, or H	112.74	100.74	-	-	141.98	129.98	100.74	29.24	62.76	50.76	4.74	41.40	74.84
350/400	I, J, or K	148.59	136.59	105.98	30.61	177.83	165.83	105.98	59.85	62.76	50.76	4.74	41.40	110.41

① Gas connection for 1st furnace. For Model sizes 500-800 add 33.5" for second furnace gas connection.
For Model sizes 840-960 add 33.50" and 67.00" for second and third furnace gas connections.

DIMENSIONS - COOLING COILS

Figure 46.1 - DX Coil Drawing (All dimensions in inches)




Table 46.1 - DX Coil Dimensions

					DX - Single Circuit ①			DX - Dual Circuit ②		
Model Size	Cooling MBH	FH	H	S	FL	I	L	FL	I	L
75	All	27.5	30.5	1.5	18	25	21	16.25	26.5	19.25
100/125	All	27.5	30.5	1.5	21	28	24	19.5	29.75	22.5
150/175	All	27.5	30.5	1.5	24	31	27	23	33.25	28.5
200/225	Below 185 MBH	32.5	34.5	0.5	27	34	30	25.5	35.75	28.5
	185 MBH & Up	32.5	34.5	0.5	27	34.5	30			
250/300	Below 185 MBH	32.5	34.5	0.5	30	37	33	28.5	38.75	31.5
	185 MBH & Up	32.5	34.5	0.5	30	37.5	33			
350/400	Below 185 MBH	32.5	34.5	0.5	42	49	45	40.25	50.5	43.25
	185 MBH & Up	32.5	34.5	0.5	42	49.5	45			

① Single Circuit DX coils have 1 each Suction Line and Liquid Lines. Refer to AccuSpec for line size diameters.
② Dual Circuit DX coils have 2 each Suction Line and Liquid Lines. Refer to AccuSpec for line size diameters.

Figure 49.2 - Chilled Water Coil Drawing (All dimensions in inches)




Table 46.2 - Chilled Water Coil Dimensions

Model Size	FH	H	S	V	FL	I	L	Supply Line	Return Line
75	27	30	1.5	1.5	16.25	25.50	19.25	1.50 MPT	1.50 MPT
100/125	27	30	1.5	1.5	19.50	28.75	22.50	1.50 MPT	1.50 MPT
150/175	27	30	1.5	1.5	23.00	32.25	26.00	1.50 MPT	1.50 MPT
200/225	33	34.5	0.5	1	25.50	34.75	28.50	1.50 MPT	1.50 MPT
250/300	33	34.5	0.5	1	28.50	37.75	31.50	1.50 MPT	1.50 MPT
350/400	33	34.5	0.5	1	40.25	49.50	43.25	1.50 MPT	1.50 MPT

WEIGHTS

Table 48.1 - Unit Operating Weights ①

Model Size	Blower Type (Digit 16)	Base Unit				Motor	Filters	Dampers		Rain-hood	Double Wall (all sections)				Evap Cooler
		Digit 2						Fresh Air Only	Fresh & Return Air		Digit 2				
		B	D	C	P						B	D	C	P	
75	All	439	540	546	647	See Motor Data	6	26	46	65	38	73	72	107	See Evaporative Cooler Data
100/125	All	474	578	584	688		6	26	46	67	38	73	72	107	
150/175	All	511	621	626	736		6	29	52	70	43	78	77	112	
200/225	All	588	707	714	833		6	29	52	72	46	86	85	125	
250/300	E,F,G, or H	626	747	756	877		8	33	60	83	46	88	87	129	
250/300	I, J, or k	875	996	1005	1126		15	33	60	83	93	135	134	176	
350/400	E,F,G, or H	738	876	887	1025		12	38	70	90	53	102	101	150	
350/400	I, J, or k	1019	1057	1168	1306		17	38	70	90	96	145	144	193	
500/600	G or H	959	1080	n/a	n/a		8	33	60	83	46	88	n/a	n/a	
500/600	I, J, k, or L	1208	1329	n/a	n/a		15	33	60	83	93	135	n/a	n/a	
700/800	G or H	1153	1291	n/a	n/a		12	38	70	90	53	102	n/a	n/a	
700/800	I, J, k, or L	1352	1490	n/a	n/a		17	38	70	90	96	145	n/a	n/a	
840/960	I, J, k, or L	1767	1905	n/a	n/a		17	38	70	90	96	145	n/a	n/a	

Table 48.2 - Motor Operating Weights ①

Digit 14 - Supply Voltage	Digit 18 - Motor Type	Digit 17 - Motor Size											
		A or L	B or M	C or N	D or P	E or Q	F or R	G or S	H or T	I or W	J or X	K or Y	V or Z
		1/3	1/2	3/4	1	1-1/2	2	3	5	7-1/2	10	15	20
A - 115/60/1ph	1 - ODP	25	23	25	32	40	49	81	-	-	-	-	-
	5 - TE	25	28	30	37	45	49	83	-	-	-	-	-
B - 208/60/1ph	1 - ODP	-	23	25	32	40	49	81	87	-	-	-	-
	5 - TE	-	28	30	37	45	49	83	86	-	-	-	-
C - 230/60/1ph	1 - ODP	25	23	25	32	40	49	81	87	-	-	-	-
	5 - TE	25	28	30	37	45	49	83	86	-	-	-	-
D - 208/60/3ph	1 - ODP	17	18	21	-	-	-	-	-	-	-	-	-
	2 - ODP HE	-	-	-	83	94	99	83	94	141	126	220	250
	5 - TE	15	23	26	-	-	-	-	-	-	-	-	-
	6 - TE HE	-	-	-	68	66	66	92	99	158	200	259	368
E - 230/60/3ph	1 - ODP	17	18	21	-	-	-	-	-	-	-	-	-
	2 - ODP HE	-	-	-	40	46	54	87	94	130	126	217	250
	5 - TE	15	23	30	-	-	-	-	-	-	-	-	-
	6 - TE HE	-	-	-	53	66	67	92	117	194	213	322	368
F - 460/60/3ph	1 - ODP	17	18	21	-	-	-	-	-	-	-	-	-
	2 - ODP HE	-	-	-	40	46	54	87	94	130	126	217	250
	5 - TE	15	23	30	-	-	-	-	-	-	-	-	-
	6 - TE HE	-	-	-	53	66	66	92	117	194	213	322	368
G - 575/60/3ph	1 - ODP	-	25	28	-	-	-	-	-	-	-	-	-
	2 - ODP HE	-	-	-	35	40	45	76	89	90	220	310	360
	5 - TE	-	24	33	-	-	-	-	-	-	-	-	-
	6 - TE HE	-	-	-	68	40	67	100	125	192	200	326	368

① All weights in pounds and are approximate.

THIS PAGE INTENTIONALLY LEFT BLANK

MAINTENANCE

⚠ WARNING

When servicing or repairing this equipment, use only factory-approved service replacement parts. A complete replacement parts list may be obtained by contacting Modine Manufacturing Company. Refer to the rating plate on the appliance for complete appliance model number, serial number, and company address. Any substitution of parts or controls not approved by the factory will be at the owner's risk.

⚠ CAUTION

Do not attempt to reuse any mechanical or electrical controllers which have been wet. Replace defective controller.

IMPORTANT

To check most of the Possible Remedies in the troubleshooting guide listed in Table 55.1, refer to the applicable sections of the manual.

All heating equipment should be serviced before each heating season to assure proper operations. The following items may be required to have more frequent service schedule based on the environment in which the unit is installed, and the frequency of the equipment operation.

Electrical Wiring

The electrical wiring should be checked annually for loose connections or deteriorated insulation.

Blower Assembly

The blower assembly includes the bearings, drive sheaves and belts. Blower bearings should be checked and lubricated based on the blower manufacturer's recommendations. Bearings should also be checked for any unusual wear and replaced if needed. Drive sheaves should be checked at the same time the bearings are inspected. Check to make sure the sheaves are in alignment and are securely fastened to the blower and motor shafts. Belt tension should be rechecked shortly after the unit has been installed to check for belt stretching. After the initial start-up, monthly checks are recommended.

Filters

If the unit is supplied with a dirty filter switch and light, clean or replace the filters any time the dirty filter light comes on.

Units which do not have a dirty filter warning light should have the filters checked monthly. Clean or replace if necessary. In dirty atmospheres, filter maintenance may be required more often.

Figure 50.1 - Filter Replacement Arrangement for STANDARD Blower Size (Model Digit 16=A through H)





Figure 50.2 - Filter Replacement Arrangement for EXTENDED Blower Size (Model Digit 16 = I, J, K, or L)



MAINTENANCE

Cooling Coil Maintenance

1. Periodically, inspect the coil for signs of corrosion and leaks. Repair and replacement of the coil and the connecting piping, valves, etc., must be performed as needed by a qualified technician.
2. Should the coil surface need cleaning, caution should be exercised in selecting the cleaning solution as well as the cleaning equipment. Improper selection can result in damage to the coil and/or health hazards. Cleaning solutions must not be corrosive or cause damage to copper tube/aluminum fin coils. Clean the coil from the leaving air-side so that foreign material will be washed out of the coil rather than pushed further in. Be sure to carefully read and follow the cleaning fluid manufacturer's recommendations before using any cleaning fluid.
3. For DX coils, replace the filter dryer(s) as needed.
4. For chilled fluid coils:
 - a. Maintain the circulated fluid free of sediment, corrosive products and biological contaminants.
 - b. Freeze Protection - During the winter, chilled water coils need to be protected against freezing. Two common methods are 1) blowing out the coils with air, or 2) flushing coils with inhibited glycol designed for corrosion protection in HVAC applications. Select an inhibited glycol solution that will protect the coil from the lowest possible temperatures that can occur at that locality.

Cooling Coil Drain Pan and Drain System

The drain pan, trap, and drain pipe must be cleaned regularly to avoid blockage that can reduce or stop water flow as follows:

1. At the beginning of the cooling season, inspect and clean the entire cooling coil cabinet and condensate drain pan to remove contaminants.
2. Inspect and clean the condensate drain trap and piping. The use of a cleanout opening at the top of the trap can help facilitate this maintenance.
3. Fill the trap with water to ensure proper operation and replace the cap on the cleanout opening to close the system.
4. During the end of cooling season shutdown of the system, disconnect and remove all water from the trap and drain to prevent freeze damage. If local building codes permit, the trap may be filled with an antifreeze solution.
5. If the unit is used year round, regularly inspect and clean the cooling coil cabinet, condensate drain pan, and trap/drain system to ensure proper function.
6. Depending on climate, freeze protection of the trap may be required during non-cooling days.

Duct Furnace

When providing annual maintenance for the duct furnace, keep the unit free from dust, dirt, grease and foreign matter. Pay particular attention to:

1. The power exhauster discharge opening and the combustion air inlet louvers.
2. The burner ports and pilot burner orifices (avoid the use of hard, sharp instruments capable of damaging surfaces for cleaning these ports). To check the burner port and pilot burner orifice, see Burner and Pilot Assembly Removal.
3. The air shutters and main burner orifices (avoid the use of hard, sharp instruments capable of damaging surfaces for cleaning these orifices). To check the air shutters and main burner orifices, see for Manifold Assembly Removal.

The heat exchanger should be checked annually for cracks and discoloration of the tubes. If a crack is detected, the heat exchanger should be replaced before the unit is put back into service. If the tubes are dark gray, airflow across the heat exchanger should be checked to insure that a blockage has not occurred or the blower is operating properly.

Gas Piping & Controls

The gas valves and piping should be checked annually for general cleanliness and tightness.

The gas controls should be checked to insure that the unit is operating properly.

(continued next page)


MAINTENANCE

Manifold Assembly Removal

To remove the manifold (Refer to Figure 52.1):

1. Shut off gas and electric supply.
2. Remove the side access panel.
3. Disconnect gas manifold at ground union joint.
4. Remove the two screws holding the manifold to the heat exchanger support.
5. Slide the manifold through the manifold bracket.
6. Clean the orifices and adjust the air shutters as necessary.
7. Follow steps 3-6 in reverse to install the manifold assembly.
8. Turn on the electric and gas supply.
9. Check the ground union joint for leaks with a soap solution. Tighten if necessary.
10. Install the side access panel.

Figure 52.1 - Manifold Assembly Removal




Burner and Pilot Assembly Removal

To remove the burner (Refer to Figure 52.2):

1. Shut off gas and electric supply.
2. Disconnect the pilot supply line from the gas valve.
3. Disconnect the ignition cable from the ignition controller (located in the electrical junction box). Feed the cable through the bushing in the bottom of the junction box.
4. Remove the screws holding the burner side access panel. Attached to the panel are the burner retaining pins that align the burner.
5. Slide the burner assembly out. The pilot is attached to the burner assembly.
6. Examine the burner and pilot assembly for cleanliness and/or obstructions as necessary (see Duct Furnace for cleaning instructions).
7. Replace the burner assembly in reverse order. In replacing the burner, be certain that the rear burner slots are located properly on the burner retaining pins. Do not force the burner side access panel, it will not fit if the burner is not properly aligned.
8. Reconnect the ignition cable and pilot gas supply line.
9. Turn on the electric and gas supply.

Figure 52.2 - Burner and Pilot Assembly Removal



THIS PAGE INTENTIONALLY LEFT BLANK

SERVICE & TROUBLESHOOTING

⚠ WARNING

When servicing or repairing this equipment, use only factory-approved service replacement parts. A complete replacement parts list may be obtained by contacting Modine Manufacturing Company. Refer to the rating plate on the unit for complete unit model number, serial number, and company address. Any substitution of parts or controls not approved by the factory will be at the owner's risk.

⚠ CAUTION

Do not reuse any mechanical or electrical component which has been wet. Such component must be replaced.

IMPORTANT


To check most of the Possible Remedies in the troubleshooting guide listed in Table 54.1, refer to the applicable sections of the manual.

Table 54.1 - Troubleshooting

Trouble	Possible Cause	Possible Remedy
Pilot does not light	1. Main gas is off.	1. Open manual gas valve.
	2. Power supply is off.	2. Turn on main power.
	3. Air in gas line.	3. Purge gas line.
	4. Dirt in pilot orifice.	4. Check for plugged pilot orifice and clean with compressed air if necessary.
	5. Gas pressure out of proper range.	5. Adjust to a minimum for Natural Gas - 6" W.C. Minimum for Propane Gas - 11" W.C. Maximum 14" W.C.
	6. Pilot valve does not open.	6. Check wiring for 24 volts to valve.
	a. Defective ignition controller.	a. Replace ignition controller.
	b. Defective gas valve.	b. Replace gas valve.
	7. No Spark at ignitor.	7
	a. Loose wire connections.	a. Check all ignition controller wiring.
	b. Pilot sensor is grounded.	b. Replace sensor if cracked or worn
	c. Defective ignition controller.	c. Replace ignition controller.
	8. Safety device has cut power.	8. Check all safety devices (High limit, air flow proving switch, power exhaustor centrifugal switch, gas pressure switches, etc.) Determine and correct problem. Reset if necessary.
Main burners do not light (Pilot is lit)	1. Defective valve.	1. Replace valve.
	2. Loose wiring.	2. Check wiring to gas valve.
	3. Defective pilot sensor	3. Replace pilot sensor.
	4. Defective ignition controller.	4. Replace ignition controller.
	5. Improper thermostat wiring.	5. Verify wiring compared to wiring diagram.
Lifting Flames (See Figure 54.1)	1. Too much primary air.	1. Reduce primary air.
	2. Main pressure set too high.	2. Adjust to a maximum of 14" W.C.
	3. Orifice too large.	3. Check orifice size with those listed on the serial plate.
Yellow Tipping (With propane gas, some yellow tipping is always present.)	1. Insufficient primary air.	1. Increase primary air.
	2. Dirty orifice.	2. Check orifices and clean with compressed air if necessary.
	3. Misaligned orifice.	3. Check manifold, replace if necessary.
Flashback	1. Too much primary air.	1. Reduce primary air.
	2. Main pressure set too high.	2. Adjust to a maximum of 14" W.C.
	3. Orifice too large.	3. Check orifice size with those listed on the serial plate.

(Continued next page)

Figure 54.1 - Lifting Flame Condition



SERVICE & TROUBLESHOOTING (CONTINUED)

Table 54.1 - Troubleshooting (Continued)

Trouble	Possible Cause	Possible Remedy
Floating Flames (See Figure 55.1)	1. Insufficient primary air.	1. Increase primary air.
	2. Main pressure set too high.	2. Adjust to a maximum of 14" W.C.
	3. Orifice too large.	3. Check orifice size with those listed on the serial plate.
	4. Blocked vent cap.	4. Clean louvers in vent cap.
Flame Rollout (See Figure 55.2)	1. Main pressure set too high.	1. Adjust to a maximum of 14" W.C.
	2. Orifice too large.	2. Check orifice size with those listed on the serial plate.
	3. Blocked vent cap.	3. Clean louvers in vent cap.
Not Enough Heat	1. Unit cycling on high limit. ①	1.
	a. Obstructions/leaks in duct system.	a. Clean/correct duct system.
	b. Main pressure set too high.	b. Adjust to a maximum of 14" W.C.
	c. Blower motor not energized.	c. Check that blower motor operates within 45 seconds of when gas controls are energized.
	d. Loose belt	d. Adjust belt tension.
	e. Blower speed too low.	e. Check/correct blower drive settings for proper rpm.
	f. Blocked/damaged venting system.	f. Check/correct venting system.
	g. Defective high limit switch.	g. Replace high limit switch.
	2. Main pressure set too low.	2. Adjust main gas pressure. (Minimum for Natural Gas — 6" W.C. Minimum for Propane Gas — 11" W.C.)
	3. Too much outside air.	3. Adjust outside air damper to decrease outside air percentage (if possible).
	4. Thermostat malfunction.	4. Check/replace thermostat.
	5. Gas controls wired incorrectly.	5. Check unit wiring against the wiring diagram.
	6. Unit undersized.	6. Check design conditions. If unit is undersized, an additional unit(s) or other heat source must be added.
Too Much Heat	1. Thermostat malfunction.	1. Check/replace thermostat.
	2. Gas controls do not shut-off.	2.
	a. Gas controls wired incorrectly.	a. Check unit wiring against the wiring diagram.
	b. Short circuit.	b. Check for loose or worn wires.
	3. Main gas pressure set too high.	3. Adjust to a maximum of 14" W.C.
Power Exhauster Motor Will Not Start	4. Defective gas valve.	4. Replace gas valve.
	1. Power supply is off.	1. Turn on main power.
	2. No 24V power to thermostat.	2. Check control transformer.
	3. Thermostat malfunction.	3. Check/replace thermostat.
	4. Defective power exhauster relay.	4. Replace power exhauster relay.
	5. Defective power exhauster motor.	5. Replace power exhauster motor.

① The duct furnace comes standard with an automatic reset high limit switch that will shut-off the gas should the discharge air temperature become excessive. See Figure 22.1, indicator (49) for the location of either the standard automatic or optional manual reset high limit switch. The switch should operate only when something is wrong with the unit operation. Anytime the switch operates, correct the difficulty immediately or serious damage may result. If the switch cuts off the gas supply during normal operation, refer to the "Not Enough Heat" section of Table 54.1.

Figure 55.1
Floating Flame Condition





Figure 55.2
Flame Rollout Appearance



THIS PAGE INTENTIONALLY LEFT BLANK

START-UP CHECKLIST

START-UP CHECKLIST INDIRECT GAS-FIRED HEATING EQUIPMENT

Job Name:	Date:	
Address:	Model No.:	
City & State:	Order No.:	
Start-Up Check List "ALL ITEMS MUST BE CHECKED"	Serial No.:	

1. All shipping straps, braces, tie downs removed?	___ Yes	___ No
2. Unit installed level and secure?	___ Yes	___ No
3. Gas burner properly located and aligned?	___ Yes	___ No
4. Blower and motor alignment okay?	___ Yes	___ No
5. Bearings aligned and tight on shaft/bearing supports?	___ Yes	___ No
6. Electrical connections checked and secure?	___ Yes	___ No
7. Gas piping checked and tightened if necessary?	___ Yes	___ No
8. Any visible damage to unit?	___ Yes	___ No
Describe: _____		
If damaged, was the damage repaired?	___ Yes	___ No
9. Air inlet and discharge checked for obstructions?	___ Yes	___ No
10. Bearings checked for proper lubrication?	___ Yes	___ No
11. Filters in place and correct to direction of air flow?	___ Yes	___ No
12. Belt tension checked?	___ Yes	___ No
13. Electric supply to unit: _____ Volts, _____ Hz, _____ Phase		
14. Gas supply to unit: _____ Natural, _____ Propane		
15. Gas supply pressure to unit: _____ " W.C., _____ PSIG		
16. Inlet and/or discharge dampers operating correctly?	___ Yes	___ No
17. Blower rotation correct?	___ Yes	___ No
18. Blower speed: Hi Speed _____ RPM, Lo Speed _____ RPM		
19. Motor speed: Hi Speed _____ RPM, Lo Speed _____ RPM		
20. Is unit noisy? Excessive vibration?	___ Yes	___ No
21. Motor voltage: L1 _____ V, L2 _____ V, L3 _____ V		
22. Motor amps: L1 _____ Amp, L2 _____ Amp, L3 _____ Amp		
23. High temperature limit control continuity checked?	___ Yes	___ No
24. Burner light off		
Low Fire: Does entire burner light off?	___ Yes	___ No
Hi Fire: Burner pressure reading? _____ " W.C.		
Is flame clean and stable?	___ Yes	___ No
Does flame modulate in response to temperature control(s)?	___ Yes	___ No
25. Gas input checked?	___ Yes	___ No
Input at maximum firing rate: _____ Btu/Hr		
Input at minimum firing rate: - _____ Btu/Hr		
26. Gas piping checked for and free of leaks?	___ Yes	___ No
27. Has wiring been verified to match the unit wiring diagram?	___ Yes	___ No
28. Have all the modes of the sequence of operation been verified and tested?	___ Yes	___ No
29. What optional and/or accessory control devices have been set?		
Device: _____ Setting: _____ (°F/psi/Inches W.C./etc.)	___ Yes	___ No
Device: _____ Setting: _____ (°F/psi/Inches W.C./etc.)	___ Yes	___ No
Device: _____ Setting: _____ (°F/psi/Inches W.C./etc.)	___ Yes	___ No

Customer/Owner instructed in operation and maintenance of unit? ___ Yes ___ No

Name of Person(s) Instructed: _____

Comments: _____

Start-Up Company Name: _____ Phone: _____

Signature: _____ Date: _____

MODEL DESIGNATIONS

Model Identification

Modine weatherproof duct furnace/make-up air units contain an ETL/ETL Canada certified weatherproof duct furnace. This duct furnace is combined with either a blower section, or a blower and/or cooling and/or downturn sections to make a complete make-up air or heating/ventilating/cooling unit that is ETL/ETL Canada certified. For this reason, two identification plates are used on these models. The **Serial Plate** is used to identify the duct furnace and its components. The **Model Identification Plate** is used to identify the complete model, including blower, cooling, and/or downturn sections.

Replacement Parts Ordering

When servicing, repairing or replacing parts on these units, locate the model identification plate of the unit and always give the complete Model Number and Serial Number from the model identification plate. The model identification plate is located on the door of the electrical control box (See Figure 58.1). For a complete description of the model number, see Model Identification.

Figure 58.1 - Serial Plate & Model ID Plate Locations




Figure 58.2 - Serial Plate (sample shown, actual data may vary)

Modine Manufacturing Company 1500 Dekoven Avenue Racine, WI 53403-2552 Phone: 800-828-4328		OUTDOOR GAS-FIRED DUCT FURNACE FOR INDUSTRIAL / COMMERCIAL USE CHAUDIERE À GAZ À CONDUIT POUR EXTERIEUR / POUR USAGE INDUSTRIEL/COMMERCIAL		Made in U.S.A.		APPROVALS DESIGN COMPLIES WITH DUCT FURNACE STANDARD: ANSI Z83.8-2013 CSA 2.6-2013 APPROVED FOR USE IN MASSACHUSETTS APPROVED FOR USE IN CA BY THE CEC	
MODEL NUMBER NUMERO DE MODELE HFP 75SMRHP40A1		MIN. INPUT DEBIT CALORIFIQUE MIN. 30000 BTU/HR W 8784		VOLTS 115		PHASE 1	
SERIAL NUMBER NUMERO DE SERIE 0917093615-0036		MIN. INPUT PRESS. FOR PURPOSE OF INPUT ADJUSTMENT / PRESSION 11 IN W.C. D'AJUSTEMENT EN P.S. MIN. LIMITE 2.74 kPa		HERTZ 60		AMPS 1.75	
TYPE OF GAS TYPE OF GAS Propane		MAK/FOLD PRESSURE PRESSION À LA TUBULURE 10 IN W.C. D'AJUSTEMENT 2.49 kPa					
TEMPERATURE RISE RANGE ELEVATION DE TEMPERATURE 20-100 °F -7- 38 °C		MAXIMUM EXTERNAL STATIC PRESSURE PRESSION STATIQUE EXTERIEURE MAXIMUM 3 IN W.C. 0.75 kPa					
INPUT DEBIT CALORIFIQUE 75000 BTU/HR W 21960		OUTPUT DEBIT CALORIFIQUE 60750 BTU/HR W 17568		MIN. CFM CMH MIN 563 16		MAX. CFM CMH MAX 2813 79	
ORIFICE SIZE DIM. DE L'ENTREE 37		MIN. VARIABLE SPEED CFM CMH 422 12		GENERAL 1. FOR OUTDOOR INSTALLATIONS ONLY. 2. MINIMUM AMBIENT TEMPERATURE -40°F. 3. FOR INSTALLATION DOWNSTREAM OF REFRIGERATION SYSTEMS. 4. INSTALL ON THE POSITIVE PRESSURE SIDE OF AIR CIRCULATING BLOWER. 5. FOR UNITS WITH MANUAL RESET HIGH LIMIT SWITCH, RESET BUTTON IS LOCATED IN ELECTRICAL JUNCTION BOX. 6. (IN USA) FOR INSTALLATIONS ABOVE 2000 FEET DERATE 4 PERCENT FOR EACH 1000 FEET OF ELEVATION ABOVE SEA LEVEL. LIGHTING INSTRUCTIONS 1. OPEN ALL GAS VALVES. TURN ON POWER. 2. SET THERMOSTAT TO DESIRED SETTING. SHUT DOWN INSTRUCTIONS: 1. TURN OFF POWER & CLOSE ALL GAS VALVES. REFER TO INSTALLATION & SERVICE MANUAL FOR MORE INSTRUCTIONS * FOR UNITS WITH 2-STAGE, MECHANICAL MODULATION, OR ELECTRONIC MODULATING GAS CONTROLS, A FACTORY DISCHARGE AIR CONTROLLER AND NO ROOM THERMOSTAT INCLUDED.			
RECOMMENDED SERVICE CLEARANCE / DÉGAGEMENT DE SERVICE RECOMMANDÉ ACCESS SIDE 18 IN CÔTÉ D'ACCÈS 45.7 CM		NON-ACCESS SIDE 6 IN CÔTÉ NON-ACCÈS 15.2 CM		COMBUSTIBLE MATERIALS AND SERVICE CLEARANCES MATÉRIAUX COMBUSTIBLES ET DÉGAGEMENTS D'ENTRÉE TOUT AIR FLOW / AIR COURANT			
COMMON REPLACEMENT PARTS For parts ordering, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description, and part number. When ordering parts, provide part number listed. For service, contact your local qualified installation and service contractor or appropriate utility company.		1. MINIMUM CLEARANCE TO COMBUSTIBLES IS 0.0" FROM BOTTOM OF UNIT MOUNTING RAIL OR 3" FROM BOTTOM OF SHEET METAL CASING. 1. LE DÉGAGEMENT MINIMUM DU COMBUSTIBLE EST 0.0CM DU BAS DE LA BARRE QUI SUPPORTE L'ÉLÉMENT OU 7.6CM DU BAS DE L'ENVELOPPE DE TÔLE.					

Figure 58.3 - Model Identification Plate (sample shown, actual data may vary)

MODEL IDENTIFICATION PLATE				MODEL NUMBER HBP960SMRHN20F2IQ5DBA00		Modine Manufacturing Company Phone: 1-800-828-4328 1500 Dekoven Avenue, Racine, WI 53403-2552 Design conforms to: UL 1995, ANSI Z83.8 - 2016 & CSA C22.6 - 2016 Certified to: CAN/CSA C22.2 No. 236 FOR SERVICE, contact your local qualified installation and service contractor or appropriate utility company. FOR PARTS ORDERING, contact the parts wholesaler or the manufacturer's representative serving your area. When inquiring about parts, always provide model number, serial number, description and part number. When ordering parts, provide part number listed.	
FAN MOTOR: SYSTEM DATA:	VOLTAGE 460		HERTZ 60		PHASE 3		
	AMPS 21.00		HP 15.0		SERIAL NUMBER 38100917090619-3193		
	SUPPLY VOLTAGE 460		HERTZ 60		ORDER V415712 18695		
	FLA 24		MCA 28		MOP (TIME DELAY) 45		
Short circuit current 5kA rms symmetrical, 460V maximum. Made in U.S.A.							

MODEL NOMENCLATURE FOR SYSTEM UNITS

Weatherproof Model Nomenclature

1	2	3	4 5 6	7	8	9	10	11	12	13	14	15	16	17	18	19	20 21	22	23
PT	UC	V	MBH	HE	DS	AS	ATR	GT	GV	SS	SV	TR	BB	HP	MT	SA	AC	EC	CC

1 - Product Type (PT)

H or O - Outdoor HVAC Unit

2 - Unit Configuration (UC)

B - Blower Package - Furnace & Blower

C - Cooling Package - Furnace, Blower, & Cooling Cabinet

D - Downturn Package - Furnace, Blower, & Downturn

P - Packaged Unit - Furnace, Blower, Cooling Cabinet, & Downturn

3 - Venting (V)

P - Power

4,5,6 - Furnace Input Rating (MBH) (Except for 840 & 960)

75 - 75,000 Btu/Hr Input	350 - 350,000 Btu/hr Input
100 - 100,000 Btu/Hr Input	400 - 400,000 Btu/Hr Input
125 - 125,000 Btu/Hr Input	500 - 500,000 Btu/Hr Input
150 - 150,000 Btu/Hr Input	600 - 600,000 Btu/Hr Input
175 - 175,000 Btu/Hr Input	700 - 700,000 Btu/Hr Input
200 - 200,000 Btu/Hr Input	800 - 800,000 Btu/Hr Input
225 - 225,000 Btu/Hr Input	840 - 1,050,000 Btu/Hr Input
250 - 250,000 Btu/Hr Input	960 - 1,200,000 Btu/Hr Input
300 - 300,000 Btu/hr Input	

7 - Heat Exchanger/Burner/Drip Pan Material (HE)

A - Aluminized Steel

S - 409 Stainless Steel Heat Exchanger/Burner

T - 409 Stainless Steel Heat Exchanger/Burner/Drip Pan

8 - Development Sequence Designation (DS)

F - Single Stage

M - 2-stage or Modulating

9 - Access Side (AS)

R - Right Hand

L - Left hand

10 - Air Temperature Rise (ATR)

H - High 60°-100°F

L - Low 20°-60°F

11 - Gas Type (GT)

N - Natural with ignition controller

P - Propane with ignition controller

12 - Gas Valve (GV)

1 - Single Stage

2 - Two Stage

4 - Electronic Modulation

7 - Electronic Modulation 0-10 Vdc External Input

8 - Electronic Modulation 4-20 mA External Input

9 - Electronic Modulation with Modine Control System

13 - Additional Safety Switches (SS)

0 - No Switches (Standard)

1 - Low Gas Pressure Switch (Premium)

2 - High Gas Pressure Switch (Premium)

3 - High and Low Gas Pressure Switch (Premium)

14 - Supply Voltage (SV)

A - 115/60/1

E - 230/60/3

B - 208/60/1

F - 460/60/3

C - 230/60/1

G - 575/60/3

D - 208/60/3

15 - Transformer (TR)

1 - 40 VA

2 - 75 VA

3 - 150 VA

4 - 250 VA

0 - None

16 - Blower Size & Bearing Type (BB)

A - 9-7 Spider Bearings

G - 15-15 Spider Bearings

B - 9-7 Pillow Block Bearings

H - 15-15 Pillow Block Bearings

C - 9-9 Spider Bearings

I - 18-18 Spider Bearings under 15 Hp

D - 9-9 Pillow Block Bearings

J - 18-18 Pillow Block Brngs under 15 Hp

E - 12-12 Spider Bearings

K - 18-18 Pillow Block Brngs, 15 Hp & Up

F - 12-12 Pillow Block Brngs

L - 20-18 Pillow Block Bearings

17 - Motor Horsepower (HP)

A - 1/3 Hp

L - 1/3 Hp with Motor Starter

B - 1/2 Hp

M - 1/2 Hp with Motor Starter

C - 3/4 Hp

N - 3/4 Hp with Motor Starter

D - 1 Hp

P - 1 Hp with Motor Starter

E - 1-1/2 Hp

Q - 1-1/2 Hp with Motor Starter

F - 2 Hp

R - 2 Hp Hp with Motor Starter

G - 3 Hp

S - 3 Hp with Motor Starter

H - 5 Hp

T - 5 Hp with Motor Starter

I - 7-1/2 Hp

W - 7-1/2 Hp with Motor Starter

J - 10 Hp

X - 10 Hp with Motor Starter

K - 15 Hp

Y - 15 Hp with Motor Starter

V - 20 Hp

Z - 20 Hp with Motor Starter

18 - Motor Type (MT)

1 - ODP

2 - ODP - High Eff.

5 - TE

6 - TE - High Eff.

19 - Sheave Arrangement (SA)

A - (See Sheave Tables)

20,21 - Air Control (AC)

AA - RA Opening

BA - FA Opening

CA - FA & RA Openings

DA - FA Dampers w/ 2 pos motor (No RA)

EA - FA & RA Dampers w/ 2 pos motor

GA - FA & RA Mod motor w/ 0-10 Vdc External Input

GB - FA & RA Mod motor w/ 4-20 mA External Input

GC - FA & RA Mod motor w/ Minimum Position (Factory Mounted)

GD - FA & RA Mod motor w/ Remote Position

GE - FA & RA Mod motor w/ 3 pos. damper (100% RA, Variable, 100% OA)

GG - FA & RA Mod motor w/ Min Position & Proportional Temp Controller

GH - FA & RA Mod motor w/ Remote Position & Prop. Temp Controller

GJ - FA & RA Mod motor w/ FA Enthalpy Controller

HP - FA & RA Floating motor w/ Space Pressure Controller

JA - Manual FA & RA Dampers

22 - Evaporative Cooling (EC)

0 - None

D - 12" GLASdek Media, Stainless Steel Casing

23 - Cooling Coil (CC)

0 - None

1 - Factory Installed Coil

COMMERCIAL WARRANTY

Seller warrants its products to be free from defects in material and workmanship, EXCLUSIVE, HOWEVER, of failures attributable to the use of materials substituted under emergency conditions for materials normally employed. This warranty covers replacement of any parts furnished from the factory of Seller, but does not cover labor of any kind and materials not furnished by Seller, or any charges for any such labor or materials, whether such labor, materials or charges thereon are due to replacement of parts, adjustments, repairs, or any other work done. This warranty does not apply to any equipment which shall have been repaired or altered outside the factory of Seller in any way so as, in the judgment of Seller, to affect its stability, nor which has been subjected to misuse, negligence, or operating conditions in excess of those for which such equipment was designed. This warranty does not cover the effects of physical or chemical properties of water or steam or other liquids or gases used in the equipment.

BUYER AGREES THAT SELLER'S WARRANTY OF ITS PRODUCTS TO BE FREE FROM DEFECT IN MATERIAL AND WORKMANSHIP, AS LIMITED HEREIN, SHALL BE IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, WHETHER ARISING FROM LAW, COURSE OF DEALING, USAGE OF TRADE, OR OTHERWISE, **THERE ARE NO OTHER WARRANTIES, INCLUDING WARRANTY OF MERCHANTABILITY OR FITNESS FOR PURPOSE, WHICH EXTEND BEYOND THE PRODUCT DESCRIPTION CONFIRMED BY BUYER AND SELLER AS OF THE DATE OF FINAL AGREEMENT.**

This warranty is void if the input to the product exceeds the rated input as indicated on the product serial plate by more than 5% on gas-fired and oil-fired units, or if the product in the judgment of SELLER has been installed in a corrosive atmosphere, or subjected to corrosive fluids or gases, been subjected to misuse, negligence, accident, excessive thermal shock, excessive humidity, physical damage, impact, abrasion, unauthorized alterations, or operation contrary to SELLER'S printed instructions, or if the serial number has been altered, defaced or removed.

BUYER AGREES THAT IN NO EVENT WILL SELLER BE LIABLE FOR COSTS OF PROCESSING, LOST PROFITS, INJURY TO GOODWILL, OR ANY OTHER CONSEQUENTIAL OR INCIDENTAL DAMAGES OF ANY KIND RESULTING FROM THE ORDER OR USE OF ITS PRODUCT, WHETHER ARISING FROM BREACH OF WARRANTY, NONCONFORMITY TO ORDERED SPECIFICATIONS, DELAY IN DELIVERY, OR ANY LOSS SUSTAINED BY THE BUYER.

BUYER'S REMEDY FOR BREACH OF WARRANTY, EXCLUSIVE OF ALL OTHER REMEDIES PROVIDED BY LAW, IS LIMITED TO REPAIR OR REPLACEMENT AT THE FACTORY OF SELLER, ANY COMPONENT WHICH SHALL, WITHIN THE APPLICABLE WARRANTY PERIOD DEFINED HEREIN AND UPON PRIOR WRITTEN APPROVAL, BE RETURNED TO SELLER WITH TRANSPORTATION CHARGES PREPAID AND WHICH THE EXAMINATION OF SELLER SHALL DISCLOSE TO HAVE BEEN DEFECTIVE; EXCEPT THAT WHEN THE PRODUCT IS TO BE USED BY BUYER AS A COMPONENT PART OF EQUIPMENT MANUFACTURED BY BUYER, BUYER'S REMEDY FOR BREACH, AS LIMITED HEREIN, SHALL BE LIMITED TO ONE YEAR FROM DATE OF SHIPMENT FROM SELLER. FOR GAS-FIRED PRODUCTS INSTALLED IN HIGH HUMIDITY APPLICATIONS AND UTILIZING STAINLESS STEEL HEAT EXCHANGERS, BUYER'S REMEDY FOR BREACH, AS LIMITED HEREIN, SHALL BE LIMITED TO TEN YEARS FROM DATE OF SHIPMENT FROM SELLER.

These warranties are issued only to the original owner-user and cannot be transferred or assigned. No provision is made in these warranties for any labor allowance or field labor participation. Seller will not honor any expenses incurred in its behalf with regard to repairs to any of Seller's products. No credit shall be issued for any defective part returned without proper written authorization (including, but not limited to, model number, serial number, date of failure, etc.) and freight prepaid.

OPTIONAL SUPPLEMENTAL WARRANTY

Provided a supplemental warranty has been purchased, Seller extends the warranty herein for an additional four (4) years on certain compressors. Provided a supplemental warranty has been purchased, Seller extends the warranty herein for an additional four (4) years or nine (9) years on certain heat exchangers.

EXCLUSION OF CONSUMABLES & CONDITIONS BEYOND SELLER'S CONTROL

This warranty shall not be applicable to any of the following items: refrigerant gas, belts, filters, fuses and other items consumed or worn out by normal wear and tear or conditions beyond Seller's control, including (without limitation as to generality) polluted or contaminated or foreign matter contained in the air or water utilized for heat exchanger (condenser) cooling or if the failure of the part is caused by improper air or water supply, or improper or incorrect sizing of power supply.

<u>Component</u> Applicable Models	"APPLICABLE WARRANTY PERIOD"
<u>Heat Exchangers</u> Gas-Fired Units except MPR Models	TEN YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN TEN YEARS FROM DATE OF RESALE BY BUYER OR ANY OTHER USER, WITHIN TEN YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN ONE HUNDRED TWENTY-SIX MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Heat Exchangers</u> Low Intensity Infrared Units , Gas Heat option on MPR models <u>Compressors</u> Condensing Units for Cassettes	FIVE YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN FIVE YEARS FROM DATE OF RESALE BY BUYER OR ANY OTHER USER, WITHIN FIVE YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN SIXTY-SIX MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Burners</u> Low Intensity Infrared Units <u>Compressors</u> MPR Models <u>Other</u> Components excluding Heat Exchangers, Coils, Condensers, Burners, Sheet Metal	TWO YEARS FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN TWO YEARS FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN THIRTY MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST
<u>Heat Exchangers/Coils</u> Indoor and Outdoor Duct Furnaces and System Units, Steam/Hot Water Units, Oil-Fired Units, Electric Units, Cassettes, Vertical Unit Ventilators <u>Compressors</u> Vertical Unit Ventilators <u>Burners</u> High Intensity Infrared Units <u>Sheet Metal Parts</u> All Products	ONE YEAR FROM DATE OF FIRST BENEFICIAL USE BY BUYER OR ANY OTHER USER, WITHIN ONE YEAR FROM DATE OF RESALE BY BUYER IN ANY UNCHANGED CONDITION, OR WITHIN EIGHTEEN MONTHS FROM DATE OF SHIPMENT FROM SELLER, WHICHEVER OCCURS FIRST

As Modine Manufacturing Company has a continuous product improvement program, it reserves the right to change design and specifications without notice.



Modine Manufacturing Company
1500 DeKoven Avenue
Racine, WI 53403
Phone: 1.800.828.4328 (HEAT)
www.modinehvac.com